

FlightSafety Textron Aviation

TRAINING



CITATION 560XL/XLS/XLS+ SERIES MAINTENANCE SCHEMATIC MANUAL

SECOND EDITION

Revision 0.3

NOTICE

Textron Aviation Inc. materials in this training program have been reproduced with permission and are copyrighted by Textron Aviation Inc.

These items are controlled by the U.S. Government and authorized for export only to the country of ultimate destination for use by the ultimate consignee or end-user(s) herein identified. They may not be resold, transferred, or otherwise disposed of, to any other country or to any person other than the authorized ultimate consignee or end-user(s), either in their original form or after being incorporated into other items, without first obtaining approval from the U.S. government or as otherwise authorized by U.S. law and regulations.

Copyright © 2019 FlightSafety Textron Aviation Training, LLC.
Unauthorized reproduction or distribution is prohibited.
All rights reserved.

INSERT LATEST REVISED PAGES, DESTROY SUPERSEDED PAGES

LIST OF EFFECTIVE PAGES

Dates of issue for original and changed pages are:

Second Edition.. 0 June 2016
Revision..... 0.1 May 2018
Revision..... 0.2 March 2019
Revision..... 0.3..... January 2020

NOTE:

Revision numbers in footers occur at the bottom of every page that has technical changes to the text and/or illustrations. Reflow of pages, grammatical, or typographical changes that do not affect the meaning are excluded from this list.

THIS PUBLICATION CONSISTS OF THE FOLLOWING:

| Page No. | *Revision No. | Page No. | *Revision No. |
|-----------------------|---------------|------------------|---------------|
| Cover | 0.3 | 27-1—27-12 | 0.0 |
| Copyright..... | 0.3 | 28-1—28-8 | 0.0 |
| LEP | 0.3 | 29-1—29-6 | 0.0 |
| Notice/Contents | 0.0 | 30-1—30-8 | 0.0 |
| vi—xii | 0.0 | 31-1—31-16 | 0.0 |
| 1-1—1-4 | 0.0 | 32-1—32-12 | 0.0 |
| 2-1—2-4 | 0.0 | 33-1—33-6 | 0.0 |
| 5-1—5-4 | 0.0 | 34-1—34-6 | 0.0 |
| 21-1 | 0.0 | 35-1—35-4 | 0.0 |
| 21-2—21-5 | 0.3 | 36-1—36-4 | 0.0 |
| 21-6—21-16 | 0.0 | 38-1—38-2 | 0.0 |
| 22-1—22-4 | 0.0 | 45-1—45-4 | 0.0 |
| 23-1—23-8 | 0.0 | 49-1—49-4 | 0.0 |
| 24-1—24-36 | 0.0 | 51-1—51-4 | 0.0 |
| 25-1—25-4 | 0.0 | 71-1—71-22 | 0.0 |
| 26-1—26-6 | 0.0 | | |

*Zero in this column indicates an original page.

NOTICE

The material contained in this training manual is based on information obtained from the aircraft manufacturer’s pilot manuals and maintenance manuals. It is to be used for familiarization and training purposes only.

At the time of printing it contained then-current information. In the event of conflict between data provided herein and that in publications issued by the manufacturer or the applicable regulatory agency, that of the manufacturer or the regulatory agency shall take precedence.

We at FlightSafety Textron Aviation Training want you to have the best training possible. We welcome any suggestions you might have for improving this manual or any other aspect of our training program.

| | |
|---------------------------|------|
| Introduction | 01 |
| ATA 100 | 02 |
| Aircraft General | 5-12 |
| Air Conditioning | 20 |
| Autoflight | 22 |
| Communications | 23 |
| Electrical Power | 24 |
| Equipment and Furnishings | 25 |
| Fire Protection | 26 |
| Flight Controls | 27 |
| Fuel | 28 |
| Hydraulic Power | 29 |
| Ice and Rain Protection | 30 |
| Indicating and Recording | 31 |

| | |
|-----------------------------------|-------|
| <u>Landing Gear</u> | 23 |
| <u>Lights</u> | 33 |
| <u>Navigation</u> | 34 |
| <u>Oxygen</u> | 35 |
| <u>Pneumatics System</u> | 36 |
| <u>Water/Waste</u> | 38 |
| <u>Central Maintenance System</u> | 45 |
| <u>Airborne Auxiliary Power</u> | 49 |
| <u>Structures</u> | 51-57 |
| <u>Powerplant</u> | 71-80 |

CONTENTS

| | Page |
|--|------|
| INTRODUCTION | 1-1 |
| ATA 100 | 2-1 |
| General | 2-1 |
| AIRCRAFT GENERAL | 5-1 |
| General | 5-1 |
| Dimensions and Areas | 5-1 |
| AIR CONDITIONING | 21-1 |
| Air Distribution—General..... | 21-1 |
| AUTO FLIGHT..... | 22-1 |
| Automatic Flight Control System (XL/XLS)..... | 22-1 |
| Automatic Flight Control System (XLS ⁺)..... | 22-1 |
| COMMUNICATIONS..... | 23-1 |
| General | 23-1 |
| ELECTRICAL POWER | 24-1 |
| General | 24-1 |
| EQUIPMENT & FURNISHINGS..... | 25-1 |
| General | 25-1 |
| FIRE PROTECTION | 26-1 |
| General | 26-1 |
| FLIGHT CONTROLS | 27-1 |
| General | 27-1 |
| FUEL..... | 28-1 |
| General | 28-1 |
| HYDRAULIC POWER | 29-1 |
| General | 29-1 |

CONTENTS

| | Page |
|---------------------------------------|-------|
| ICE AND RAIN PROTECTION | 30-1 |
| General | 30-1 |
| INDICATING AND RECORDING SYSTEMS..... | 31-1 |
| General | 31-1 |
| Rotary Test Knob (XL/XLS) | 31-14 |
| AVN..... | 31-14 |
| LANDING GEAR | 32-1 |
| General | 32-1 |
| LIGHTS | 33-1 |
| General | 33-1 |
| NAVIGATION | 34-1 |
| General | 34-1 |
| OXYGEN..... | 35-1 |
| General | 35-1 |
| Oxygen System Description..... | 35-1 |
| PNEUMATIC SYSTEM..... | 36-1 |
| General | 36-1 |
| WATER/WASTE..... | 38-1 |
| General | 38-1 |
| CENTRAL MAINTENANCE SYSTEM..... | 45-1 |
| General | 45-1 |
| Operation..... | 45-3 |
| AIRBORNE AUXILIARY POWER..... | 49-1 |
| General | 49-1 |
| STRUCTURES | 51-1 |

CONTENTS

| | |
|------------------|------|
| | Page |
| General | 51-1 |
| POWERPLANT | 71-1 |
| General | 71-1 |

ILLUSTRATIONS

| Figure | Title | Page |
|--------|---|-------|
| 1-1 | Citation Excel Instrument Panel Poster | 1-2 |
| 1-2 | Citation XLS Instrument Panel Poster | 1-3 |
| 1-3 | Citation XLS+ Instrument Panel Poster | 1-4 |
| 2-1 | Symbology List and Description | 2-2 |
| 5-1 | Airplane Dimensions..... | 5-2 |
| 5-2 | Airplane Zones..... | 5-3 |
| 21-1 | Temperature Control..... | 21-2 |
| 21-2 | Pressurization—ACM Overheat..... | 21-6 |
| 21-3 | Pressurization..... | 21-7 |
| 21-4 | Emergency Pressurization | 21-9 |
| 21-5 | Air Distribution Overview Schematic..... | 21-11 |
| 21-6 | Air Distribution Sources..... | 21-12 |
| 21-7 | Air Distribution..... | 21-13 |
| 21-8 | Kollsman Pressurization System..... | 21-16 |
| 22-1 | Primus 1000 Block Diagram (XL/XLS) | 22-2 |
| 22-2 | Primus 1000 Block Diagram (XLS 5500 thru 6000)..... | 22-3 |
| 22-3 | Autoflight System Block Diagram (XLS+)..... | 22-4 |
| 23-1 | Communications Controls (XL/XLS) | 23-2 |
| 23-2 | Communications Block Diagram (XL/XLS)..... | 23-3 |
| 23-3 | Antenna Locations (XL)..... | 23-4 |
| 23-4 | Antenna Locations (XLS)..... | 23-5 |
| 23-5 | Communications Controls (XLS+) | 23-6 |
| 23-6 | Communications Block Diagram (XLS+)..... | 23-7 |
| 23-7 | Antenna Locations (XLS+) | 23-8 |

ILLUSTRATIONS

| Figure | Title | Page |
|--------|--|-------|
| 24-1 | Battery Power..... | 24-2 |
| 24-2 | Battery Start..... | 24-3 |
| 24-3 | Generator Assisted Start..... | 24-4 |
| 24-4 | Generators Online | 24-5 |
| 24-5 | APU Start..... | 24-6 |
| 24-6 | APU Generator Online | 24-7 |
| 24-7 | APU Assisted Start..... | 24-8 |
| 24-8 | External Power Unit Starts | 24-10 |
| 24-9 | Generator Control Unit (GCU) | 24-14 |
| 24-10 | Simplified Electrical System—Battery Connected | 24-16 |
| 24-11 | Simplified Electrical System—Battery Switch On | 24-18 |
| 24-12 | Generator Control Unit (GCU)—With Battery Switch On..... | 24-20 |
| 24-13 | Simplified Electrical System—Battery Start RH Engine | 24-22 |
| 24-14 | Generator Control Unit (GCU)—During Engine Start | 24-24 |
| 24-15 | Simplified Electrical System—RH Generator Online | 24-26 |
| 24-16 | Generator Control Unit (GCU)—With Generator Online..... | 24-28 |
| 24-17 | Simplified Electrical System—Generator Assist Start On LH Engine | 24-30 |
| 24-18 | Simplified Electrical System—External Power Connected | 24-32 |
| 24-19 | Simplified Electrical System—External Power Start | 24-34 |
| 25-1 | Floor Plan (XL/XLS) | 25-2 |
| 25-2 | Floor Plan with Options (XLS+) | 25-3 |
| 25-3 | Artex ELT 110-4 Locator Beacon System | 25-4 |
| 26-1 | Fire Protection—Right Engine Fire—RH Engine Fire Switch Pressed..... | 26-2 |
| 26-2 | Fire Protection—First Bottle | 26-3 |

ILLUSTRATIONS

| Figure | Title | Page |
|--------|--|-------|
| 26-3 | Fire Protection—Second Bottle | 26-4 |
| 26-4 | Fire Protection—Right Engine Fire Out | 26-5 |
| 27-1 | Flight Controls Overview | 27-2 |
| 27-2 | Rudder Bias | 27-3 |
| 27-3 | Stabilizer—Up | 27-6 |
| 27-4 | Stabilizer and Flaps in Transition for Takeoff/Landing | 27-7 |
| 27-5 | Horizontal Stabilizer Control | 27-8 |
| 27-6 | Speed Brake Operation..... | 27-10 |
| 28-1 | Fuel Flow—Normal..... | 28-2 |
| 28-2 | Fuel Flow—LH Crossfeed..... | 28-3 |
| 28-3 | Fuel Control System..... | 28-4 |
| 28-4 | Single Point Refuel/Defuel System Overview..... | 28-7 |
| 29-1 | Hydraulics—Engines Running | 29-2 |
| 29-2 | Hydraulics—ON..... | 29-3 |
| 29-3 | Hydraulics ON—Speed Brake Control Valve Energized | 29-4 |
| 29-4 | Hydraulic Pressure ON—Horizontal Stabilizer Control Valve Energized..... | 29-5 |
| 30-1 | Engine Anti-Ice—ON | 30-2 |
| 30-2 | Tail De-Ice—Deflated | 30-3 |
| 30-3 | Tail De-Ice—Inflated (Manual) | 30-4 |
| 30-4 | Wing/Engine Anti-Ice..... | 30-5 |
| 30-5 | Wing/Engine Anti-Ice—OFF | 30-7 |
| 30-6 | Windshield Anti-Ice Overview | 30-8 |
| 31-1 | Annunciator Panel..... | 31-2 |
| 32-1 | Landing Gear Hydraulic System Overview..... | 32-2 |

ILLUSTRATIONS

| Figure | Title | Page |
|--------|---|-------|
| 32-2 | Landing Gear Retracting | 32-3 |
| 32-3 | Landing Gear Extending..... | 32-4 |
| 32-4 | Landing Gear Emergency Extension..... | 32-5 |
| 32-5 | Landing Gear Control and Landing Gear Warning (Retracting) (XL/XLS) | 32-6 |
| 32-6 | Landing Gear Control and Landing Gear Warning (Retracted) (XL/XLS) | 32-7 |
| 32-7 | Landing Gear Control and Landing Gear Warning (Extending with Nose Gear Down and Locked) (XL/XLS)..... | 32-8 |
| 32-8 | Landing Gear Control and Landing Gear Warning (Extended) (XL/XLS)..... | 32-9 |
| 32-9 | Landing Gear Electrical—Down and Locked (XLS+)..... | 32-10 |
| 32-10 | Landing Gear Electrical—In Transit Up (XLS+) | 32-11 |
| 32-11 | Landing Gear Electrical—Up and Locked (XLS+) | 32-12 |
| 33-1 | Lighting Control (XL/XLS)..... | 33-2 |
| 33-2 | Lighting Controls (XLS+) | 33-3 |
| 33-3 | Interior Passenger Lights and Controls (XL/XLS/XLS+)..... | 33-4 |
| 33-4 | Exterior Lights (XL/XLS/XLS+)..... | 33-5 |
| 34-1 | Citation XL Pitot-Static Overview Block Diagram..... | 34-2 |
| 34-2 | Navigation System (XLS)..... | 34-3 |
| 34-3 | Primus 1000 Avionics Diagram (XLS) | 34-4 |
| 34-4 | Proline 21 Avionics System Diagram (XLS+)..... | 34-6 |
| 35-1 | Oxygen System—Normal..... | 35-2 |
| 35-2 | Oxygen System—OFF..... | 35-3 |
| 35-3 | Oxygen System—ON | 35-4 |
| 36-1 | Bleed Air Precooler Overview—Units 5001-5500 | 36-2 |
| 36-2 | LH Bleed Air Precooler Overview—Units 5501-5616, 5618-6000 (Right Side Typical) | 36-3 |

ILLUSTRATIONS

| Figure | Title | Page |
|--------|--|-------|
| 36-3 | LH Bleed Air Precooler Overview—Units 5617, 6001 and Subsequent (Right Side Typical) | 36-3 |
| 36-4 | Bleed Air System—ON | 36-4 |
| 38-1 | Externally Serviceable Toilet Assembly..... | 38-2 |
| 45-1 | Collins MDC System Components | 45-2 |
| 49-1 | APU Fuel System Overview | 49-2 |
| 49-2 | APU Pneumatic System Overview | 49-3 |
| 49-3 | Electronic Control Unit (ECU) and Generator Control Unit (GCU) Overview | 49-4 |
| 51-1 | Fuselage Sections..... | 51-2 |
| 51-2 | Cabin Windows | 51-3 |
| 71-1 | PW545 A/B Engine | 71-2 |
| 71-2 | PW545C Engine..... | 71-4 |
| 71-3 | Bleed Valve Control Schematic | 71-6 |
| 71-4 | Engine Fuel System (545A/B)..... | 71-7 |
| 71-5 | Engine Fuel System Overview (545C)..... | 71-8 |
| 71-6 | Ignition | 71-10 |
| 71-7 | Rudder Bias and Thrust Reversers..... | 71-14 |
| 71-8 | Left Thrust Reversers—Normal Stow | 71-15 |
| 71-9 | Left Thrust Reverser—Armed and Unlocked..... | 71-16 |
| 71-10 | Left Thrust Reversers—Normal Deploy | 71-17 |
| 71-11 | Left Thrust Reverser—Emergency Stowed | 71-18 |
| 71-12 | L Start Procedures—5001-5268 | 71-19 |
| 71-13 | XL/XLS Start Procedures 5269 and Subsequent..... | 71-20 |
| 71-14 | XLS+ Start Procedure “A”..... | 71-21 |

ILLUSTRATIONS

| Figure | Title | Page |
|--------|-------------------------------|-------|
| 71-15 | XLS+ Start Procedure “B”..... | 71-22 |


TABLES

| Table | Title | Page |
|-------|-------------------------------|-------|
| 31-1 | Annunciator Panel Lights..... | 31-3 |
| 31-2 | Annunciator lights..... | 31-5 |
| 31-3 | Red EICAS Messages..... | 31-6 |
| 31-4 | Amber EICAS Messages | 31-7 |
| 31-5 | White EICAS Messages | 31-12 |
| 31-6 | Test Indications (XLS+) | 31-16 |

CHAPTER 1

INTRODUCTION

01



INTRODUCTION

This training manual provides a description of the major airframe and engine systems as installed in the Cessna Citation 560 Excel series aircraft. This information is intended as an instructional aid only; it does not supersede, nor is it meant to substitute for, any of the manufacturer's maintenance or operating manuals. This material has been prepared from the basic design data, and all subsequent changes in aircraft appearance or system operation will be covered during academic training and subsequent revisions to this manual.

NOTES




Figure 1-1. Citation Excel Instrument Panel Poster

NOTES

01




Figure 1-2. Citation XLS Instrument Panel Poster

NOTES

01



Figure 1-3. Citation XLS+ Instrument Panel Poster

CHAPTER 2

ATA 100

02



INTRODUCTION

The purpose of this chapter is to describe the arrangement, numbering system, and special features of the *Air Transport Association (ATA)* format for aircraft maintenance manuals. To take advantage of all the material presented in an ATA 100 manual, the maintenance technician must become thoroughly familiar with the outline and contents presented for any given airplane.

GENERAL

The Cessna Citation 560XL/XLS/XLS+ Maintenance Manual, Illustrated Parts Catalog, and Wiring Diagram Manual are prepared in accordance with the Air Transport Association Specification No. 100 for manufacturer's technical data.


These manuals have been prepared to assist maintenance personnel in servicing and maintaining Citation airplanes. They provide the necessary information required to enable the mechanic to service, inspect, trouble-shoot, remove and replace components, or repair systems.

02

BATTERY




BUS




CAP AND STOW



CAPACITOR




CIRCUIT BREAKER



CONNECTOR




CURRENT SENSOR



Current flowing in coil opens switch to indicate circuit is functioning correctly.

CURRENT TRANSFORMER



Current flowing in wire produces a voltage in coil.


DIODE




REGULAR — Low resistance forward, high resistance reverse.




ZENER — Low resistance forward, high resistance reverse until a specific voltage is applied, then conducts freely.



TRANZORB — A tranzorb is similar to a zener, but with higher peak current limit.



VARISTOR — High resistance either way until a specific voltage is applied, then conducts freely. Example: V47ZA1 conducts freely above 47 volts.



VARISTOR — Encapsulated for moisture protection.

FILTER



Passes direct current but opposes pulsating current used to reduce noise in sensitive avionics equipment.


GROUND



HEADSET



HEATER




HORN/SPEAKER




INTEGRATED CIRCUIT


Integrated circuits do not necessarily work on the principle of ON-OFF as a switch; instead some work on high and low voltage. Example: high might be 5.0 volts and low might be 0.5 volts.




AND GATE — Output is low until both inputs are high; then the output is high.




NAND GATE — Output is high until both inputs are high; then the output is low.




OR GATE — Output is low until either or both inputs are high, then output is high.




NOR GATE — Output is high until either or both inputs are high; then output is low.



INVERTER — Output is low when input is high; output is high when input is low.



OPERATIONAL AMPLIFIER (OP AMP) — Amplifies the difference in voltage between the two inputs. The minus input is the inverting input, and the plus is the non-inverting input. If an input is applied to the minus input, with the plus input grounded, the polarity of the output will be opposite to the input. If an input is applied to the plus input, with the minus input grounded, the polarity of the output will be the same as that of the input.




TIMER — Changes the output from high to low in a regular pattern.

LAMP




MOTOR




Basic symbol for motor.



REVERSIBLE MOTOR — Direction of rotation is controlled by reversing power and ground on input wires.



REVERSIBLE MOTOR — Direction of rotation is controlled by applying power to either field winding input wire.



NONREVERSIBLE MOTOR — Direction of rotation is controlled by design; input wires may be connected either way.




NONREVERSIBLE MOTOR — Two speed controlled by applying power to either input wire.

FUSE/LIMITER




PHONE JACK




The symbol for the solenoid may be a box or a coil; the operation is identical.

RELAY




CURRENT FLOW WITH POWER APPLIED


CURRENT FLOW THE INSTANT POWER IS REMOVED



A diode is connected across the input wires of relays and solenoid operated devices such as valves to protect voltage sensitive navigation and electronics equipment. The diode is reverse-biased for normal power and no current flows through the diode. Current flowing through the coil of wire produces a magnetic field to operate the relay or valve. The instant power is removed from the coil, the collapsing magnetic field produces a momentary spike of high voltage which can be several hundred volts depending on the current and the number of turns of wire in the coil. The diode is forward-biased for the power generated in the coil and the high voltage spike is dissipated through the diode. A varistor is used in place of the diode on some relays.



As annunciator relay has a connection on the material contact to indicate by a light or annunciator panel when the relay is energized.



The contacts of a time delay relay do not move to the energized position usually when power is applied.




For some time delay relays, the delay time is part of the relay design.

For some time delay relays, the delay time is controlled by the size of an external resistor.

Jumper wire gives 0.1 seconds of delay.

160.000 OHM resistor gives a 10-second delay.

Other resistors give a delay time between 0.1 second and 1.0 second.



RESISTOR



REGULAR — Resistance does not change.



TEMPERATURE CONTROLLED — Resistance change with the temperature.



VARIABLE OR ADJUSTABLE — Resistance changes with mechanical input.

Figure 2-1. Symboly List and Description (Sheet 1 of 2)



2-3

NOTES

02

CHAPTER 5-12

AIRCRAFT GENERAL



5-12

INTRODUCTION

This chapter includes illustrations and statistical information concerning the Citation XL/XLS/XLS+ series aircraft. Provided are overall aircraft dimensions, station locations, aircraft zoning, location of major structural members and components. Information is also provided concerning ground handling, servicing information and inspection requirements

GENERAL

Information is provided on airworthiness and limitations, time limits and checks, continuous inspection program, dimensions, areas, locations and zoning. Information is also provided concerning access panels and plates, jacking practices, leveling and weighing, towing, taxiing and parking. A section on servicing and replenishing is provided for components, valves, filters, fuel, batteries, pneumatics, hydraulics, lubricants, cleaning materials, and deicing fluids.

Dimensions and measurements are presented to aid the operator and/or maintenance personnel in ground handling the aircraft and locating the components. Measurements are expressed in feet (meters), inches (millimeters), and degrees.

DIMENSIONS AND AREAS

This Section includes illustrations and statistical information concerning the Citation XL/XLS/XLS+ aircraft. Provided are overall aircraft dimensions, surface areas, station locations, location of major structural members, access plates, panels, floorboards, fairings, aircraft zoning and aircraft drain locations.

Description

This section identifies dimensions and areas of the aircraft and aircraft components in tabular form. Dimensions are selected for pertinent information of measurements that will aid the operator in providing storage, passing through hangar doors, covering isolated areas of the aircraft, and building/ordering maintenance stands. The dimensions are expressed in feet, inches, degrees, and minutes. Aircraft assembly areas are expressed in square feet.



[illegible]

Figure 5-1. Airplane Dimensions

NOTES

5-12




Figure 5-2. Airplane Zones

NOTES

5-12

5-4

FOR TRAINING PURPOSES ONLY

Revision 0

CHAPTER 21

AIR CONDITIONING



21

INTRODUCTION

This Chapter describes the air distribution, air conditioning, and pressurization systems on the model 560 XL/XLS/XLS⁺ aircraft. These three separate but interrelated systems are presented in three sections. Information is provided regarding air distribution within the cabin and how it is controlled. The components and their operation for the air conditioning (vapor cycle cooling) system and pressurization system are also discussed. References for this chapter and further specific information can be found in Chapter\ 5—“Time Limits/Maintenance Checks,” Chapter 12—“Servicing,” Chapter 21—“Air Conditioning,” and Chapter 36—“Pneumatics” of the *Aircraft Maintenance Manual (AMM)*.

AIR DISTRIBUTION—GENERAL

This section describes the devices and components used to create cool air/warm air, the methods of distributing this air to each area of the aircraft, and pressurization. The 560 XL/XLS/XLS⁺ uses a single allied signal environmental control unit (ECU) to transform hot engine [or

auxiliary power unit (APU)] bleed air to cool conditioned air. This cooled conditioned air is available for use in the cool air distribution system or mixed with hot bleed air for the warm air distribution system.

NOTES

21









Figure 21-1. Temperature Control (Sheet 1 of 4)



NOTES



LEGEND

- COLD ACM (TURBINE) DISCHARGE AIR
- ENGINE BLEED AIR
- PRECOOLED AIR
- COMPRESSOR DISCHARGE AIR
- CONDITIONED AIR
- PRIMARY HEAT EXCHANGE AIR
- SECONDARY HEAT EXCHANGE AIR
- ACM EXHAUST
- APU BLEED AIR

CONDITION:
TEMP CONTROL—NORMAL
APU RUNNING
APU BLEED VALVE OPEN

Figure 21-1. Temperature Control (Sheet 2 of 4)

NOTES

21





Figure 21-1. Temperature Control (Sheet 3 of 4)



NOTES




Figure 21-1. Temperature Control (Sheet 4 of 4)




LEGEND

ENGINE BLEED AIR


PRECOOLED AIR

APU BLEED AIR

CONDITION:
ACM—OVERHEAT
LH FLOW CONTROL VALVE—CLOSED
RH FLOW CONTROL VALVE—CLOSED



21



NOTES

Figure 21-2. Pressurization—ACM Overheat

NOTES

21








Figure 21-3. Pressurization (Sheet 2 of 2)



NOTES



LEGEND

- COLD ACM (TURBINE) DISCHARGE AIR
- ENGINE BLEED AIR
- PRECOOLED AIR
- COMPRESSOR DISCHARGE AIR
- PRIMARY HEAT EXCHANGE AIR
- SECONDARY HEAT EXCHANGE AIR
- ACM EXHAUST
- APU BLEED AIR

CONDITION:
 IN AIR
 ACM—OVERHEAT
 EMERGENCY PRESSURIZATION VALVE—OPEN

Figure 21-4. Emergency Pressurization (Sheet 1 of 2)

NOTES

21




Figure 21-4. Emergency Pressurization (Sheet 2 of 2)

NOTES

21




Figure 21-5. Air Distribution Overview Schematic

LEGEND

COLD ACM (TURBINE) DISCHARGE AIR

ENGINE BLEED AIR

PRECOOLED AIR

COMPRESSOR DISCHARGE AIR

PRIMARY HEAT EXCHANGE AIR




SECONDARY HEAT EXCHANGE AIR

ACM EXHAUST

APU BLEED AIR

CONDITION:

PRESS SOURCE—NORM
APU BLEED—ON



NOTES








Figure 21-6. Air Distribution Sources



NOTES

Figure 21-7. Air Distribution (Sheet 1 of 3)

LEGEND

- COLD ACM (TURBINE) DISCHARGE AIR
- ENGINE BLEED AIR
- PRECOOLED AIR
- COMPRESSOR DISCHARGE AIR
- PRIMARY HEAT EXCHANGE AIR
- SECONDARY HEAT EXCHANGE AIR
- ACM EXHAUST
- APU BLEED AIR

CONDITION:
LH PRESS SOURCE—SELECTED
RH MASS FLOW VALVE—CLOSED

NOTES

21







Figure 21-7. Air Distribution (Sheet 2 of 3)



NOTES



LEGEND

- COLD ACM (TURBINE) DISCHARGE AIR
- ENGINE BLEED AIR
- PRECOOLED AIR
- COMPRESSOR DISCHARGE AIR
- PRIMARY HEAT EXCHANGE AIR
- SECONDARY HEAT EXCHANGE AIR
- ACM EXHAUST
- APU BLEED AIR

CONDITION:
PRESS SOURCE—OFF
RH MASS FLOW VALVE—CLOSED
LH MASS FLOW VALVE—CLOSED

Figure 21-7. Air Distribution (Sheet 3 of 3)

NOTES





Figure 21-8. Kollsman Pressurization System

Notes section with horizontal lines for recording information.

CHAPTER 22

AUTO FLIGHT



22

INTRODUCTION

The autopilot section describes the portion of the system controlling the flight path of the airplane through adjustment to pitch, roll, or yaw, autopilot servos and associated cables. This section provides maintenance information on the autopilot servo, autopilot controller, servo bracket, cable drum, and servo cables. Individual servos are installed to control aileron, rudder, and elevator surface positions. The autopilot system is integrated with the flight director.

AUTOMATIC FLIGHT CONTROL SYSTEM (XL/XLS)

The automatic flight control system (AFCS) consists of two IC-600 display guidance computers—one MS-560 flight director/autopilot mode selector, one PC-400 autopilot controller and three flight control SM200 servos (pitch, roll and yaw).

Features of the autopilot system include:

- Yaw damping
- Elevator trim
- Heading hold
- Pitch hold
- Bank limit modes
- Touch-control-steering

The coupling of flight director modes with autopilot engagement is also featured.


Three flight maneuvering options are available to the pilot, manual operation, automatic operation or manual control using the autopilot.

AUTOMATIC FLIGHT CONTROL SYSTEM (XLS+)

The Collins flight guidance system has a FGP-3000 flight guidance panel (FGP) that is installed in the upper center instrument panel in the fire tray. The FGP has lateral and vertical mode selection switches, heading and course control knobs, a speed knob, an altitude alert/altitude preselect knob, a VS pitch control wheel, and autopilot and yaw damper controls. The autopilot and yaw damper controls include

autopilot engage, yaw damper engage, couple switch, and yaw damper/autopilot disconnect. The FGP also has dual flight director controls.

The FGC-3000 flight guidance computer modules are a component of the integrated avionics processor system (IAPS) that is installed inside the ICC- 31 11 integrated card cage (ICC) in the right side nose avionics compartment. The FGC modules control the data for the Collins flight guidance system. The FGC modules send the commands to the aileron, elevator, and rudder autopilot servos for the three-axis autopilot control.



NOTES




Figure 22-2. Primus 1000 Block Diagram (XLS 5500 thru 6000)

NOTES




Figure 22-3. Autoflight System Block Diagram (XLS+)

CHAPTER 23

COMMUNICATIONS



23


INTRODUCTION


This chapter describes and provides maintenance information for systems and components that furnish a means of communicating from one part of the aircraft to another, or between the aircraft and other aircraft or ground stations. Also included are the passenger address and voice recording systems. Each Model 560 Excel aircraft is delivered with a complete set of avionics wiring diagrams. These diagrams, which are to be carried aboard the aircraft, must be used in conjunction with this manual when performing maintenance on aircraft. Technical publications, available from manufacturers of components and systems, must be utilized as required for maintenance of those components and systems.

GENERAL

Various antennas are used on the model 560XL/XLS for navigation and communications. The aircraft has a high frequency system to provide long range communications, a digital telecommunications system, an automatic flight information system (AFIS), passenger

address, and entertainment systems. Information is also provided on the audio integrating system, static discharging system, cockpit voice recorder, and integrated radio system.






NOTES


| | | |
|--|--|--|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

Figure 23-2. Communications Block Diagram (XL/XLS)



NOTES


Figure 23-3. Antenna Locations (XL)



NOTES

| | | |
|--|--|--|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |


Figure 23-4. Antenna Locations (XLS)



NOTES

| | | |
|--|--|--|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

Figure 23-6. Communications Block Diagram (XLS+)




NOTES

| | | |
|--|--|--|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

Figure 23-7. Antenna Locations (XLS+)

CHAPTER 24

ELECTRICAL POWER



24

INTRODUCTION


This chapter describes the electrical power system network used on the Model 560XL/XLS/XLS+. Information is included on direct current (DC) and alternating current (AC) systems. Descriptive coverage of the electrical system consists of power sources, generation, distribution, and system monitoring. Provisions are also made for a limited supply of power during in-flight emergency conditions and for connection of external power while on the ground. References for this chapter and further specific information can be found in Chapters 5—“Time Limits/Maintenance Checks,” Chapter 12—“Servicing,” and Chapter 24—“Electrical Power,” of the *Aircraft Maintenance Manual (AMM)*.

GENERAL

The Model 560XL incorporates DC and AC electrical systems. DC electrical power is required for operation and control of main aircraft systems such as hydraulics, environmental, and anti-ice systems. AC electrical power is required for windshield anti-ice and is provided by an engine-driven alternator. The primary source of DC electrical power is provided by two starter-generators on the engines that are connected in parallel to a common bus system, for equal load sharing. A nickel-cadmium or lead acid battery or an optional onboard auxiliary power unit (APU) provides secondary/backup DC power sources. Provision for connecting an external power supply (EPU) when on the ground is also included.

Current limiters and circuit breakers protect all electrical buses, wiring, and equipment. Backup and emergency power supplies (with associated buses and circuits) are incorporated to provide adequate electrical power for both AC and DC essential equipment during emergency operations. Positioning the battery switch to EMER enables the crew to reduce electrical loads by removing power from nonessential equipment, while maintaining essential electrical power during emergency situations (caused by a loss of primary power). A DC voltmeter, ammeter gauges, annunciator, and master warning switchlights provide monitoring capability for the electrical system.


24



CONDITION:
BATTERY CONNECTED
• Battery voltage is supplied to the Hot Battery Bus through the battery connector

LEGEND


| | | | |
|-----------------------|------------------------|-----------------------|----------------|
| BATTERY POWER | RIGHT ALTERNATOR POWER | LEFT ALTERNATOR POWER | EXTERNAL POWER |
| RIGHT GENERATOR POWER | LEFT GENERATOR POWER | APU POWER | GROUND |



CONDITION:
BATTERY SWITCH IN THE "EMER" POSITION
• EMER POWER RELAY is energized
• Voltage feeds through the energized set of contacts of the EMER PWR RELAY to the emer system buses
• Voltage then feeds through the relaxed contacts of the AVN EMER RELAY to the emer avionics buses

NOTES

Figure 24-1. Battery Power



CONDITION:
BATTERY SWITCH IN THE "ON" POSITION


- BATTERY ISOLATION RELAY is energized closed
- Voltage feeds through the relaxed set of contacts of the EMER PWR RELAY to the emer system buses
- Interior master relay is also energized closed due to the interior master switch being in the guarded position

| | | | |
|---|--|--|---|
| LEGEND | | | |
| BATTERY POWER | RIGHT ALTERNATOR POWER | LEFT ALTERNATOR POWER | EXTERNAL POWER |
| RIGHT GENERATOR POWER | LEFT GENERATOR POWER | APU POWER | GROUND |

NOTES

| | | |
|--|--|--|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |


Figure 24-2. Battery Start



CONDITION:
RH ENGINE START









- RH start button was pressed and released
- RH START RELAY is energized closed causing the start button light to illuminate and battery power to supply the RH starter/generator

24




CONDITION:
RH GENERATOR ONLINE

- The RH start relay is no longer energized closed since the engine accelerated past 42-46% N₂
- RH GEN switch is in the "ON" position which is the correct position for battery starts
- The RH GEN RELAY is energized closed supplying all of the buses with 28.5 volts from the RH Gen.

| LEGEND | | | |
|---|--|---|--|
|  BATTERY POWER |  RIGHT ALTERNATOR POWER |  LEFT ALTERNATOR POWER |  EXTERNAL POWER |
|  RIGHT GENERATOR POWER |  LEFT GENERATOR POWER |  APU POWER |  GROUND |


NOTES



CONDITION:
LH ENGINE START (GENERATOR ASSIST)

- LH start button was pressed and released
- BATTERY ISOLATION RELAY is de-energized open
- Both LH and RH START RELAYS are energized closed, illuminating both start buttons and providing a path for RH gen and Battery power to supply the LH start/generator

Figure 24-3. Generator Assisted Start











CONDITION:

LH GENERATOR ONLINE


- The start relays are no longer energized closed since the LH engine accelerated past 42-46% N_2
- Both GEN switches are in the "ON" position which is the correct position for the battery starts
- Both GEN RELAYS are energized closed supplying all of the buses with 28.5 volts from both Gens.

LEGEND

 BATTERY POWER
  RIGHT ALTERNATOR POWER
  LEFT ALTERNATOR POWER
  EXTERNAL POWER

 RIGHT GENERATOR POWER
  LEFT GENERATOR POWER
  APU POWER
  GROUND


NOTES



CONDITION:



AVIONICS POWER ON

- AVIONICS POWER switch has been placed in the "ON" position
- The AVN EMER RELAY and both AVN PWR RELAYS are de-energized closed to supply voltage to all of the avionics buses



CONDITION:
BATTERY SWITCH ON

- Battery voltage is supplied to the Hot Battery Bus through the battery connector




CONDITION:
APU START

- APU START/STOP switch momentarily placed in start
- The APU START RELAY is energized closed illuminating the "APU RELAY ENGAGED" annunciator and supplying power to the APU starter/generator









NOTES


Figure 24-5. APU Start



CONDITION:
APU RUNNING

- At approx. 50% speed the start sequence terminates and the APU START RELAY re-closes extinguishing the "APU RELAY ENGAGED" annunciator
- The apu continues to accelerate to 100% speed (idle) at which point the "READY TO LOAD" annunciator will illuminate

| | | | |
|---|-----------------------|---|------------------------|
| LEGEND | | | |
|  | BATTERY POWER |  | RIGHT ALTERNATOR POWER |
|  | RIGHT GENERATOR POWER |  | LEFT ALTERNATOR POWER |
|  | LEFT GENERATOR POWER |  | APU POWER |
|  | EXTERNAL POWER |  | GROUND |




CONDITION:
APU GENERATOR ON LINE

- APU GENERATOR switch was placed in the "ON" position
- The APU GENERATOR RELAY closed providing APU gen power to the crossfeed bus and on to all of the system buses

NOTES

Figure 24-6. APU Generator Online



24






CONDITION:

RH ENGINE START


- The RH START button was pressed and released
- The RH START RELAY closed illuminating the start button light
- The APU START RELAY closed illuminating the apu relay engaged annunciator

NOTE: Pre-Service Publication 24-14

LEGEND

- BATTERY POWER
 RIGHT GENERATOR POWER
  RIGHT ALTERNATOR POWER
  LEFT GENERATOR POWER
  LEFT ALTERNATOR POWER
  EXTERNAL POWER
  GROUND

NOTES




CONDITION:

APU AND RH GENERATORS ONLINE

- The start relays are no longer energized closed since the RH engine accelerated past 42-46% N₂
- Both GEN switches are in the "ON" position which is the correct position for engine starts using the APU
- The RH GEN RELAY is energized closed

Figure 24-7. APU Assisted Start (Sheet 1 of 2)



CONDITION:





LH ENGINE START (GENERATOR ASSIST)

- LH START button was pressed and released
- The APU and both LH and RH start relays are energized closed illuminating both start buttons and the APU relay engaged annunciator
- The Battery Isolation relay is de-energized open protecting the 225A current limiters


NOTE: Pre-Service Publication 24-14

LEGEND

 BATTERY POWER
 RIGHT ALTERNATOR POWER
 LEFT ALTERNATOR POWER
 EXTERNAL POWER

 RIGHT GENERATOR POWER
  LEFT GENERATOR POWER
  APU POWER
  GROUND

NOTES




CONDITION:

LH GENERATOR ONLINE

- The start relays are no longer energized closed nor is the battery isolation relay de-energized open since the LH engine accelerated past 42-46% N₂
- The LH gen relay closed supplying the system buses with the power from both main engine generators and the APU generator

Figure 24-7. APU Assisted Start (Sheet 2 of 2)

24




CONDITION:
EPU CONNECTED

- The external power unit is producing 28 vdc and is connected to the aircraft
- Since the EPU voltage is less than 32.5 vdc and with no aircraft generators on line, the EXTERNAL POWER RELAY is energized closed providing EPU power to the Hot Battery Bus and also to the aircraft battery

| | | | |
|-----------------------|------------------------|-----------------------|----------------|
| LEGEND | | | |
| BATTERY POWER | RIGHT ALTERNATOR POWER | LEFT ALTERNATOR POWER | EXTERNAL POWER |
| RIGHT GENERATOR POWER | LEFT GENERATOR POWER | APU POWER | GROUND |


NOTES



CONDITION:
BATTERY SWITCH—"ON"

- Placing the battery switch in the "ON" position, the BATTERY ISOLATION RELAY is energized closed
- All of the system buses are now receiving EPU power

Figure 24-8. External Power Unit Starts (Sheet 1 of 4)




CONDITION:
RH ENGINE START

- RH start button was pressed and released
- RH START RELAY is energized closed causing the start button light to illuminate and EPU power to supply the RH starter/generator
- The BATT DISC RELAY is energized open to prevent the battery from assisting with the start

LEGEND

| | | | |
|-----------------------|------------------------|-----------------------|----------------|
| BATTERY POWER | RIGHT ALTERNATOR POWER | LEFT ALTERNATOR POWER | EXTERNAL POWER |
| RIGHT GENERATOR POWER | LEFT GENERATOR POWER | APU POWER | GROUND |


NOTES



CONDITION:
RH ENGINE RUNNING

- The RH START RELAY is no longer energized closed nor is the BATT DISC RELAY energized open since the engine accelerated past 42-46% N₂
- The RH generator will produce 28.5 vdc, but its power will not be supplied to the buses since "OFF" is the correct generator switch position for EPU starts

Figure 24-8. External Power Unit Starts (Sheet 2 of 4)




CONDITION:
LH ENGINE START

- LH start button was pressed and released
- LH START RELAY is energized closed causing the start button light to illuminate and EPU power to supply the LH starter/generator
- The BATT DISC RELAY is energized open to prevent the battery from assisting with the start

LEGEND

| | | | |
|-----------------------|------------------------|-----------------------|----------------|
| BATTERY POWER | RIGHT ALTERNATOR POWER | LEFT ALTERNATOR POWER | EXTERNAL POWER |
| RIGHT GENERATOR POWER | LEFT GENERATOR POWER | APU POWER | GROUND |


NOTES



CONDITION:
LH ENGINE RUNNING

- The LH START RELAY is no longer energized closed nor is the BATT DISC RELAY energized open since the engine accelerated past 42-46% N₂
- The LH generator will produce 28.5 vdc, but its power will not be supplied to the buses since "OFF" is the correct generator switch position for EPU starts

Figure 24-8. External Power Unit Starts (Sheet 3 of 4)




CONDITION:
EPU DISCONNECTED

- Per the checklist, the EPU should be disconnected prior to placing the generators on line
- When the EPU power plug is removed, the EXT PWR RELAY will be de-energized open
- The cockpit voltmeter will drop back down to Battery voltage of 24-25 vdc

LEGEND

| | | | |
|---|--|--|---|
| BATTERY POWER | RIGHT ALTERNATOR POWER | LEFT ALTERNATOR POWER | EXTERNAL POWER |
| RIGHT GENERATOR POWER | LEFT GENERATOR POWER | APU POWER | GROUND |

NOTES





CONDITION:
LH AND RH GENERATORS ONLINE

- After the EPU is disconnected, the GEN switches are placed in the "ON" position
- The LH and RH GEN RELAYS are energized closed supplying all of the system buses with 28.5 vdc from the two engine generators which are then sharing the current load

Figure 24-8. External Power Unit Starts (Sheet 4 of 4)

NOTES



VIEW A-A

NOTE: OBSERVE INFORMATION ON THE PLACARD TO PREVENT DAMAGE TO THE GENERATOR CONTROL UNIT.

Figure 24-9. Generator Control Unit (GCU)

[illegible]



24-16

BATTERY CONNECTED

Conditions

- 1. Battery plugged in.

Objectives

- 1. Connect battery to hot battery bus.
- 2. Provide power to battery relay, left and right start relays, and left and right K2 PCB relays.

Sequence of Events

- 1. Power applied to hot battery bus.
- 2. Power on pin 19 of the left and right start PCB's applies power to the K2 relays.

NOTES




Figure 24-11. Simplified Electrical System—Battery Switch On

BATTERY SWITCH ON

Conditions

- 1. Battery switch ON

Objectives

- 1. Energize the battery relay closed to connect the hot battery bus to the crossfeed bus.
- 2. Energize the left and right K2 PCB relays closed.

Sequence of Events

- 1. Both K2 PCB relays energized closed because of ground provided on pin 16 of both start PCB's through the battery switch.
- 2. Power applied to PAL and one contact of K1 on both start PCB's.
- 3. Discrete ground input to PAL provided on pin 16 of both start PCB's through the battery switch.
- 4. PAL causes ground on Pin 17 of right and left start PCB's energizing the battery relay closed.

NOTES




Figure 24-12. Generator Control Unit (GCU)—With Battery Switch On

[illegible]




Figure 24-13. Simplified Electrical System—Battery Start RH Engine

BATTERY START RH ENGINE

Conditions

1. Battery start of the right engine


Objectives

1. Close the right start relay.
2. Engage latching circuit for start relay and K1.

Sequence of Events

1. Pressing the right start button provides momentary ground input on pin 23 of right start PCB.
2. Power output from PAL causes K1 PAL relay to initially energize, closing 2 sets of contacts.
 - A. One set of contacts short Pins 21 & 22 of start PCB together disabling ground fault sensing circuit of GCU.
 - B. Other set of contacts apply power to pin 10 of the start PCB. The following circuits are affected.
 - (1) Overhead floodlights ON full bright
 - (2) Power to Ignition Power Relay (no effect until throttle is positioned in idle).
 - (3) Power to pin 7 of fuel PCB causing fuel boost pump to come ON.
 - (4) Power to pin A of GCU.
3. Power on pin A of GCU supplies power on pins J and L to pins 3 & 4 of the right start PCB.
4. Power to PAL from pin 3 of start PCB activates the following circuits.
 - a) Ground on pin 6 of right start PCB energizes the start relay closed.
 - b) Start relay circuit and PAL relay (K1) circuit are latched ON.
5. Start switch is released removing ground on pin 23 of start PCB.

NOTES



[illegible]




Figure 24-15. Simplified Electrical System—RH Generator Online

RH GENERATOR ONLINE

Conditions

1. Engine speed of approximately 42-46% N₂.

Objectives

1. Release latching circuit terminating start of right engine.
2. Close power relay to connect right generator to feed bus.

Sequence of Events

1. Start is terminated as:
 - A. Speed sensing monopole provides inputs in on pins X & Y of the GCU.
 - B. GCU logic interrupts power out on pin J of the GCU.
 - C. This releases the latching circuit of pin 3 of the PCB affecting the following circuits.
 - (1) PAL relay (K1) opens.
 - (2) Start relay circuit opens as ground is removed on pin 6.
2. Power relay is closed as:
 - A. If generator switch is ON, power is applied to pin 12 of the start PCB.
 - B. GCU logic allows power to continue out on pin L of GCU to pin 4 of start PCB.
 - C. Power in on pins 4 & 12 to the PAL energizes the circuit that provides a ground for pin 14.
3. An input on pin 18 of the right start PCB provides generator power to the PAL.

NOTES

This image shows a single sheet of white paper with horizontal blue or grey ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.




Figure 24-16. Generator Control Unit (GCU)—With Generator Online

[illegible]




Figure 24-17. Simplified Electrical System—Generator Assist Start On LH Engine

GENERATOR ASSIST START ON LH ENGINE

Conditions

1. Generator assisted start of left engine.

Objectives

1. Open the battery relay.
2. Close both right and left start relays.

Sequence of Events

1. Squat Switch PCB (NZ006) provides a ground on pin 7 of both start PCB's.
2. With generator on line, power out of pin L of right GCU is applied to pin 15 of left start PCB.
3. Momentary ground on pin 23 of left start PCB affects the following circuits.
 - A. Opens the ground circuit on pin 17 of the left start PCB.
 - B. Initiates the start of the left engine.
4. Power output from PAL causes K1 PAL relay to initially energize, closing 2 sets of contacts.
 - A. One set of contacts short Pins 21 & 22 of start PCB together disabling ground fault sensing circuit of GCU.
 - B. Other set of contacts applies power to pin 10 of the start PCB. The following circuits are affected.
 - (1) Overhead floodlights ON full bright
 - (2) Power to pin 5 of ignition PCB (no effect until throttle is positioned in idle).
 - (3) Power to pin 7 of fuel PCB causing fuel boost pump to come ON.
 - (4) Power to pin A of GCU.
5. Power on pin A of GCU supplies power on pins J and L to pins 3 & 4 of the left start PCB and pins 5 and 15 of right start PCB.
6. Power to PAL from pin 3 of left start PCB activates the following circuits.
 1. Ground on pin 6 of left start PCB energizes the start relay closed after an open appears on pin 37.
 2. Start relay circuit and PAL relay (K1) circuit are latched ON.

7. Power in on pins 5 & 15 combined with generator power on pins 4 & 12 of the right start PCB affects the following circuits.
 - A. Ground on pin 17 of right start PCB opens. Battery relay opens.
 - B. Causes a ground on pin 6 of the right start PCB when an open appears on pin 37. The right start relay closes.

NOTES




Figure 24-18. Simplified Electrical System—External Power Connected

EXTERNAL POWER CONNECTED

Conditions

1. External power connected.

Objectives

1. Connect external power to the power distribution system.

Sequence of Events

1. Connect external power plug to receptacle.
 - A. External power Unit voltage passes through the External Power Control Relay's relaxed contact and goes to the External Power Relay.
 - B. External Power Unit voltage is supplied to the overvoltage monitor.
 - C. If the EPU voltage is < 32.5 vdc, then the overvoltage monitor will supply a ground for the External Power Relay.
2. External power relay closes applying power to hot battery bus.
 - A. Power in on pin 13 of both start PCB's
3. Position battery switch in BATT.
 - A. Both K2 PCB relays energized closed because of ground provided on pin 16 of both start PCB's through the battery switch.
 - B. Discrete ground input to PAL provided on pin 16 of both start PCB's through the battery switch.
 - C. PAL causes ground on Pin 17 of right and left start PCB's energizing the battery relay closed.
 - D. External power charges battery and is connected to crossfeed bus.

NOTE

If there is an input to pin 4 (generator on) or pin 15 (other side generate) of the either start PCB with an open on pins 3 or 5, there will be a ground supplied on pin 1 and the external power relay will open.

NOTES




Figure 24-19. Simplified Electrical System—External Power Start

EXTERNAL POWER START RH ENGINE

CONDITIONS

1. External power start (right engine)

OBJECTIVES

1. Energize open the battery disconnect relay
2. Initiate the right start circuit.
3. Latch the start circuit.

SEQUENCE OF EVENTS

1. Ground on pin 7 of both start PCB's.
2. Ground on pin 23 of right start PCB.
3. Battery disconnect relay opens when either of the following occurs:
 - A. Power in on pins 13 (external power on), 3 & 4 (start power from right GCU) provides a ground on pin 2 of the right start PCB.
 - B. Power in on pins 13 (external power on), 5 & 15 (start power from right GCU) provides a ground on pin 2 of the left start PCB.
4. Right start relay closes when:
 - A. Power output from PAL causes K1 PAL relay to initially energize, closing 2 sets of contacts.
 - (1) One set of contacts short Pins 21 & 22 of start PCB together disabling ground fault sensing circuit of GCU.
 - (2) Other set of contacts apply power to pin 10 of the start PCB. The following circuits are affected.
 - a. Overhead floodlights ON full bright
 - b. Power to pin 5 of ignition PCB (no effect until throttle is positioned in idle).
 - c. Power to pin 7 of fuel PCB causing fuel boost pump to come ON.
 - d. Power to pin A of GCU.
 - B. Power on pin A of GCU supplies power on pins J and L to pins 3 & 4 of the right start PCB.
 - C. Power to PAL from pin 3 of start PCB activates the following circuits.
 - (1) Ground on pin 6 of right start PCB energizes the start relay closed.
 - (2) Start relay

NOTES

NOTES

24

CHAPTER 25

EQUIPMENT & FURNISHINGS



25

INTRODUCTION

This chapter provides information on the equipment and furnishings in the Citation XL/XLS/XLS+ flight compartment, passenger compartment and baggage compartment. Emergency equipment and insulation are also included in this chapter. Special order equipment/furnishings are not defined in this chapter.

GENERAL

This chapter is divided into sections and subsections to assist maintenance personnel in locating specific equipment and furnishings. A brief description of each section herein is as follows.

The Flight Compartment section—Describes the upholstery, trim and equipment in the flight compartment. It includes the headliner, window trim, windshield trim, upholstery, glare shield, pedestal covers, sunvisors, carpet, seats and equipment, such as navigational chart cases, oxygen masks and smoke goggles.

The Passenger Compartment section—Describes equipment and furnishings within the passenger compartment. It includes the headliner, passenger service units (PSU), upholstery, trim, carpet, seats, couch, dividers, forward closet, tables, seat drawers, magazine racks and storage cabinets.

The Refreshment Center section—Describes maintenance practices for the standard and optional refreshment centers. The storage cabinets are also included in this section.

The Vanity section—Describes the standard and deluxe vanity with sink.

The Baggage Compartment section—Describes the upholstery within the baggage compartment. It also includes loose equipment.

The Emergency Equipment section—Describes the locator transmitter system, life vests and water barrier.

The Insulation section—Describes the insulation and acoustical dampening material that is installed in the aircraft.

[illegible]

25-2

NOTES




Figure 25-2. Floor Plan with Options (XLS+)

Notes section with horizontal lines for writing.

NOTES




Figure 25-3. Artex ELT 110-4 Locator Beacon System

CHAPTER 26

FIRE PROTECTION



INTRODUCTION

This chapter presents the fire protection system on the Citation 560XL/XLS/XLS⁺ aircraft. Included in this chapter is discussion of fire detection and fire-extinguishing systems, along with detailed discussion of the fire detection system control unit. Components and their operation are listed in addition to general maintenance considerations and functional and operational checks. References for this chapter and further specific information can be found in Chapters 5—“Time Limits/Maintenance Checks,” Chapter 12—“Servicing,” and Chapter 26—“Fire Protection,” of the *Aircraft Maintenance Manual (AMM)*.

GENERAL

Fire protection for the 560XL/XLS aircraft consists of a detection system and extinguishing system. Provisions for fire detection are installed in the left and right engine compartments and consist of a closed-loop sensing system and detector control unit that illuminates the respective red LH–RH ENGINE FIRE switchlights on the cockpit glareshield when a fire or overheat condition is present. The warning light, under a transparent, spring-loaded guard, also serves as a firewall shutoff switch. Fire annunciation on the XLS⁺ will also result in the MASTER WARNING flashing as well as the ENGINE FIRE L–R red CAS message and associated aural annunciation.

The fire-extinguishing system provided for the engine compartments actuates by lifting the guard and depressing the LH–RH ENGINE FIRE switchlights. This simultaneously closes the respective firewall fuel and hydraulic valves, deenergizes the starter-generator, and arms the two extinguishing bottles.

XL/XLS—The firewall shutoff and extinguisher arming are indicated by illumination of the respective L–R LO FUEL PRESS, L–R LO HYD FLOW, F/W SHUTOFF, L–R GEN OFF annunciators, and both white BOTTLE 1–2 ARMED PUSH switchlights.

XLS⁺—The firewall shutoff and extinguisher arming are indicated by illumination of the respective ENGINE FAIL L–R red CAS message, DC GENERATOR FAIL L–R, HYDRAULIC FLOW LOW L–R, WINDSHIELD HEAT INOP L–R amber CAS messages, FIREWALL SHUTOFF L–R white CAS message, and both white BOTTLE 1–2 ARMED PUSH switchlights.

Once armed, either bottle can be discharged to the selected engine by pushing the BOTTLE 1 or BOTTLE 2 ARMED PUSH switchlight. The switchlight will extinguish when it is pushed. Both bottles can be directed to the same engine if necessary.

NOTES

LEGEND

■ FIRE BOTTLE #1

■ FIRE BOTTLE #2

CONDITION:
RIGHT ENGINE FIRE
RIGHT ENGINE FIRE SWITCH—PRESSED
BOTTLE #1 ARM SWITCH—PRESSED

| | | | | | | | | | | | | | |
|--------------------|----------------------|----------------------|--------------------|---------------------------|---------------------------------|----------------------------------|--------------------------------|------------------------------|------------------------------|-----------------------------|----------------------------|----------------------|-----------------------|
| BATT OTEMP >160 | CAB ALT | LO OIL PRESS L R | LO HYD FLOW L R | LO HYD LEVEL HYD PRESS | STAB MIS COMP SPD BRK EXTEND | ENG VIB L R | OIL FLTR BP L R | GND IDLE NO TAKEOFF | P/S HTR L R | EMER PRESS ACM O'HEAT | | AHRS AUX PWR 1 2 | ENG ANTI-ICE L R |
| FUEL GAUGE L R | LO FUEL LEVEL L R | EEC MANUAL L R | GEN OFF L R | AFT J-BOX LMT CB | AC BEARING L R | RUDDER BIAS FIRE EXT BOTL LOW | FUEL FLTR BP L R | LO BRK PRESS ANTISKD INOP | STBY P/S HTR AOA HTR FAIL | AIR DUCT O'HEAT CKPT CAB | RADOME FAN | TL DEICE FAIL L R | TL DEICE PRESS L R |
| FUEL XFEED | FUEL BOOST L R | LO FUEL PRESS L R | W/S FAULT L R | W/S O'HEAT L R | F/W SHUTOFF L R | FIRE DET SYS L R | ACC DOOR UNLOCKED NOSE TAIL | DOOR SEAL CABIN DOOR | EMER EXIT LAV DOOR | BLD AIR O'HEAT L R | CHECK PFD 1 CHECK PFD 2 | WING O'HEAT L R | WING ANTI-ICE L R |







Figure 26-2. Fire Protection—First Bottle

LEGEND

-  FIRE BOTTLE #1
-  FIRE BOTTLE #2
-  FIRE BOTTLE EMPTY

CONDITION:

RIGHT ENGINE FIRE
RIGHT ENGINE FIRE SWITCH—PRESSED
BOTTLE #1 ARM SWITCH—PRESSED
BOTTLE #2 ARM SWITCH—PRESSED



NOTES




Figure 26-3. Fire Protection—Second Bottle

LEGEND

- FIRE BOTTLE #1
- FIRE BOTTLE #2
- FIRE BOTTLE EMPTY

CONDITION:
 RIGHT ENGINE FIRE SWITCH—PRESSED
 BOTTLE #1 ARM SWITCH—PRESSED
 BOTTLE #2 ARM SWITCH—PRESSED
 RIGHT ENGINE FIRE EXTINGUISHED

| | | | | | | | | | | | | | |
|--------------------|----------------------|----------------------|--------------------|---------------------------|---------------------------------|----------------------------------|--------------------------------|------------------------------|------------------------------|-----------------------------|----------------------------|----------------------|-----------------------|
| BATT OTEMP >160 | CAB ALT | LO OIL PRESS L R | LO HYD FLOW L R | LO HYD LEVEL HYD PRESS | STAB MIS COMP SPD BRK EXTEND | ENG VIB L R | OIL FLTR BP L R | GND IDLE NO TAKEOFF | P/S HTR L R | EMER PRESS ACM O'HEAT | | AHRS AUX PWR 1 2 | ENG ANTI-ICE L R |
| FUEL GAUGE L R | LO FUEL LEVEL L R | EEC MANUAL L R | GEN OFF L R | AFT J-BOX LMT CB | AC BEARING L R | RUDDER BIAS FIRE EXT BOTL LOW | FUEL FLTR BP L R | LO BRK PRESS ANTISKD INOP | STBY P/S HTR AOA HTR FAIL | AIR DUCT O'HEAT CKPT CAB | RADOME FAN | TL DEICE FAIL L R | TL DEICE PRESS L R |
| FUEL XFEED | FUEL BOOST L R | LO FUEL PRESS L R | W/S FAULT L R | W/S O'HEAT L R | F/W SHUTOFF L R | FIRE DET SYS L R | ACC DOOR UNLOCKED NOSE TAIL | DOOR SEAL CABIN DOOR | EMER EXIT LAV DOOR | BLD AIR O'HEAT L R | CHECK PFD 1 CHECK PFD 2 | WING O'HEAT L R | WING ANTI-ICE L R |

NOTES




Figure 26-4. Fire Protection—Right Engine Fire Out

NOTES

[illegible]

CHAPTER 27

FLIGHT CONTROLS



INTRODUCTION

This chapter provides a description of the flight control systems used on the 560XL/XLS/XLS+ aircraft, with a description of components and their operation. General maintenance considerations are included, with an introduction to functional and operational checks. References for this chapter and further specific information can be found in Chapter 5—“Time Limits/Maintenance Checks,” Chapter 12—“Servicing,” Chapter 20—“Standard Practices-Airframe,” and Chapter 27—“Flight Controls,” of the *Aircraft Maintenance Manual (AMM)*.

GENERAL

Primary flight controls include elevators, ailerons, and rudder which are mechanically operated and controlled. They control the aircraft movement about the three axes of flight (pitch, roll, and yaw). Trim devices are attached and operated either mechanically or electrically. Flaps that increase lift and drag are actuated hydraulically and

controlled mechanically. Speedbrakes that produce drag and slow the aircraft are hydraulically actuated and manually controlled. A pneumatic rudder bias system reduces rudder pedal force to achieve directional control during single engine operations. Warning and indicating systems are also provided.

NOTES





Figure 27-1. Flight Controls Overview

Notes section with 20 horizontal lines for recording information.



NOTES

Notes section with horizontal lines for recording information.

Figure 27-2. Rudder Bias (Sheet 1 of 3)

NOTES






Figure 27-2. Rudder Bias (Sheet 2 of 3)






NOTES

Notes section with horizontal lines for recording information.

Figure 27-2. Rudder Bias (Sheet 3 of 3)




LEGEND

-  LOW HYDRAULIC PRESSURE
-  HIGH HYDRAULIC SUPPLY PRESSURE
-  RETURN PRESSURE



CONDITION:
STABILIZER—UP
FLAPS—UP

NOTES

This image shows a single page of white paper with horizontal blue ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.



NOTES





LEGEND

- POWER
- GROUND

NOTES

Figure 27-5. Horizontal Stabilizer Control (Sheet 1 of 2)

CITATION 560XL/XLS/XLS+ SERIES MAINTENANCE SCHEMATIC MANUAL



LEGEND

- POWER
- GROUND

NOTES

Figure 27-5. Horizontal Stabilizer Control (Sheet 2 of 2)

NOTES





Figure 27-6. Speed Brake Operation (Sheet 2 of 3)

NOTES



CHAPTER 28

FUEL



INTRODUCTION

This chapter presents the fuel system for the Citation 560 XL/XLS/XLS+ aircraft and is limited to the airframe fuel system only. System discussion begins from the point of fueling the aircraft and continues to delivery of fuel to the engine, with emphasis given to components and their operation. General maintenance considerations are included, accompanied by functional and operational checks. References for this chapter can be found in Chapters 5—“Time Limits/Maintenance Checks,” Chapter 12—“Servicing,” and Chapter 28—“Fuel,” of the *Aircraft Maintenance Manual (AMM)*.

GENERAL

The sections contained in this chapter include:

- Fuel storage
- Single-point refuel/defuel
- Fuel distribution
- Fuel crossfeed
- Fuel indicating

The storage section covers:

- Ventilation systems
- Cell and tank interconnectors
- Overwing filler necks and caps
- Reservoir feed pumping systems
- Reservoirs within the tanks which are not a part of the distribution system (vent tank), etc.

The distribution section contains general coverage of the portion of the system used to distribute fuel from the filler connector to the storage system. It also covers the portion from the storage system, including the powerplant fuel quick-disconnect and single-point refueling/defueling system, as well as the crossfeed system. Items such as plumbing, pumps, valves, controls, etc, are included.

The indicating section contains pictorial and general coverage of that portion of the system used to indicate the quantity and temperature of the fuel. This does not include engine fuel flow or pressure.




Figure 28-1. Fuel Flow—Normal



NOTES

[illegible]

LEGEND

- BOOST PUMP PRESSURE
- MOTIVE FLOW PRESSURE
- PRIMARY EJECTOR PUMP PRESSURE
- TRANSFER PUMP PRESSURE



CONDITION
CROSSFEED—LH FUEL TANK TO RH ENGINE



NOTES

Notes section with horizontal lines for recording information.

Figure 28-2. Fuel Flow—LH Crossfeed



NOTES






Figure 28-3. Fuel Control System (Sheet 1 of 3)



NOTES






Figure 28-3. Fuel Control System (Sheet 2 of 3)



LEGEND
POWER
GROUND

NOTES

Figure 28-3. Fuel Control System (Sheet 3 of 3)

NOTES




Figure 28-4. Single Point Refuel/Defuel System Overview

NOTES

[illegible]

CHAPTER 29

HYDRAULIC POWER



INTRODUCTION

This chapter presents the hydraulic system for the 560XL/XLS/XLS+ Citation aircraft with special emphasis given to components and their operation. General maintenance considerations are included, with an introduction to functional and operational checks. References for this chapter and further specific information can be found in Chapters 5—“Time Limits/Maintenance Checks,” Chapter 12—“Servicing,” and Chapter 29— “Hydraulic Power,” of the *Aircraft Maintenance Manual (AMM)*.

GENERAL

The hydraulic power system operates the landing gear, speedbrakes, and thrust reversers, in addition to the flaps and horizontal stabilizer actuator.

The system includes:

- Hydraulic reservoir
- Firewall shutoff valves
- Hydraulic pumps
- Panel and filter components

The hydraulic system is classified as “open-center” because fluid continually circulates between the hydraulic pumps and the reservoir at approximately 60 psi, when there is no demand on the system. When a demand is made for system pressure by initiating operation of a subsystem, a bypass valve closes causing the pressure to increase. Pressure is determined by the system relief valve and does not exceed 1,500 psi. The system remains pressurized until the subsystem being actuated completes its cycle. It then depressurizes as the bypass valve opens. A separate independent system is employed for the main wheel antiskid/power brake system.





Figure 29-1. Hydraulics—Engines Running



NOTES

Figure 29-2. Hydraulics—ON





Figure 29-3. Hydraulics ON—Speed Brake Control Valve Energized



NOTES

Figure 29-4. Hydraulic Pressure ON—Horizontal Stabilizer Control Valve Energized

NOTES

[illegible]

CHAPTER 30

ICE AND RAIN PROTECTION



INTRODUCTION

This chapter presents the ice and rain protection systems found in the Citation 560XL/XLS/XLS+ aircraft, and has been divided into seven sections. These sections are engine anti-ice, wing anti-ice, tail deice, windshield rain removal, windshield anti-ice, pitot/static anti-ice, and the heated drains. General maintenance considerations are included in each section along with a description of components and their operation. References for this chapter and further specific information can be found in Chapters 5—“Time Limits/Maintenance Checks,” Chapter 12—“Servicing,” Chapter 30—“Ice and Rain Protection,” and Chapter 36—“Pneumatics,” of the *Aircraft Maintenance Manual (AMM)*.

GENERAL

This chapter describes the systems and components which prevent or dislodge ice formation on various exterior areas of the aircraft. Preventing ice formation is identified herein as anti-ice and dislodging ice formation is identified as deice.

Areas protected from the formation of ice by anti-ice systems are:

- Inboard/outboard wing leading edge
- Engine air intake nacelles
- Pitot/static ports

- AOA vane
- Overboard water drain lines

These areas have anti-ice systems which either heat the area with hot engine bleed air or electrical heating elements.

The horizontal stabilizer is protected by pneumatic boots which periodically inflate to dislodge or break up accumulated ice.


The windshield anti-ice system includes electrically heated glass windshields and forward side windows, combined with a forced air windshield moisture/rain removal system.


The pitot static anti-ice systems are comprised of electrically heated pitot tubes and electrically heated static ports.


Ice is detected by visual verification of ice being present. The wing inspection lights and the ice detection lights facilitate in verifying ice is present.



LEGEND

 HP BLEED AIR

 WARM (PRECOOLED) AIR

 RAM AIR

CONDITION:

ENGINE ANTI-ICE—ON

WING ANTI-ICE—OFF

NOTES

30

NOTES





Figure 30-2. Tail De-Ice—Deflated



LEGEND

- PRECOOLED SERVICE AIR
- VACUUM PRESSURE
- DE-ICE BOOT PRESSURE

CONDITION:
TAIL—INFLATED (MANUAL)

NOTES




Figure 30-3. Tail De-Ice—Inflated (Manual)

Notes section with horizontal lines for recording information.





Figure 30-4. Wing/Engine Anti-Ice (Sheet 1 of 2)


NOTES



NOTES

Notes section with horizontal lines for recording information.

Figure 30-4. Wing/Engine Anti-Ice (Sheet 2 of 2)



NOTES

[illegible]




Figure 30-6. Windshield Anti-Ice Overview

CHAPTER 31

INDICATING AND RECORDING SYSTEMS



INTRODUCTION

This chapter describes and pictorially presents instruments, control panels, and components not related to a specific system. Information is also provided on components that record, store, compute data, and give visual or aural warnings from unrelated systems.

GENERAL

This section covers the standard configurations of the instrument panel. The four individual panels described include:

- Left panel
- Center panel
- Right panel
- Tilt panel

Instruments on the panels include:

- Rotary TEST knob
- Digital clock
- Flight hour meter
- Flight data recorders
- Optics switches
- MASTER CAUTION and MASTER WARNING lights

Description

The instrument panel mounts all flight, engine, and miscellaneous instruments. There are also control panels and switches on the instrument panel.

Most of the instruments are on the front side of the instrument panel and do not require removal of the individual panel for instrument maintenance.

The control panels are illuminated by electroluminescent panels. For maintenance practices of these panels, refer to Chapter 33—"Flight Compartment Primary Lights—Maintenance Practices" in the *Aircraft Maintenance Manual (AMM)*.

For CB panel maintenance, refer to Chapter 24—"Circuit Breaker Panel—Maintenance Practices" in the *AMM*.
























XL/XLS

NOTES

Figure 31-1. Annunciator Panel












NOTES














| ANNUNCIATOR | DESCRIPTION | ANNUNCIATOR | DESCRIPTION |
|---|--|---|--|
|  | The FUEL FLTR BP light illuminates to indicate an impending bypass of the respective fuel filter. |  | The W/S O'HEAT light illuminates to indicate an overheat condition (>140°F) of the windshield. |
|  | The LO BRK PRESS light illuminates to indicate loss of power brake pressure below 750 psi. The ANTI SKD INOP light illuminates to indicate that the anti-skid system is inoperative in test mode, or the switch is off. It will also illuminate along with the LO BRK PRESS annunciator. |  | The F/W SHUTOFF light illuminates to indicate the respective fuel & hydraulic firewall shutoff valves are both closed. |
|  | The STBY P/S HTR light illuminates to indicate loss of DC power to the standby pitot static heat system. The AOA HTR FAIL light illuminates to indicate loss of DC power to the angle of attack probe heater. |  | The FIRE DET SYS light illuminates to indicate a failure in the respective fire detection system. |
|  | The AIR DUCT O'HEAT light illuminates to indicate the supply air duct to the cabin or cockpit has exceeded 300°F. |  | The ACC DOOR UNLOCKED NOSE light illuminates to indicate that at least one of four nose avionics door latches is not secure. The ACC DOOR UNLOCKED TAIL light illuminates to indicate either the forward tail cone access door, the baggage compartment door, or the battery door is not secure. |
|  | The RADOME FAN light illuminates to warn of failure of the radome cooling fan. FDR FAIL Advisory—Indicates the optional flight data recorder is inoperative (not used on XLS). |  | The DOOR SEAL light illuminates to warn of pressure less than 5.5 psid in the cabin door seal. The CABIN DOOR light illuminates to indicate that the cabin door is not locked properly and/or the vent door did not close. |
|  | The TL DEICE FAIL light illuminates to indicate the respective horizontal stab deice boot is not inflating properly less than 16 psi. |  | The EMER EXIT light illuminates to warn the emergency exit door is open. The LAV DOOR light illuminates to indicate that the interior lavatory door is not latched open with flaps down. |
|  | The TL DEICE PRESS light illuminates to indicate the respective horizontal stab deice boot is inflating and pressure is greater than 16 psi. |  | The BLD AIR O'HEAT light illuminates to indicate the respective bleed air system has exceeded 560°F. |
|  | The FUEL XFEED light illuminates to indicate the fuel crossfeed valve has opened. The light will flash if crossfeed switch is in off and the crossfeed valve is still open for greater than 10 seconds. Does not illuminate if crossfeed valve does not fully open when crossfeed is selected. |  | The CHECK PFD 1 light illuminates to indicate the pilot flight display system is not operating properly. The CHECK PFD 2 light illuminates to indicate the copilot flight display system is not operating properly. |
|  | The FUEL BOOST light illuminates to indicate the activation of the electric boost pump. (automatic or manual activation) |  | The WING O'HEAT light illuminates to indicate the air temperature between the wing leading edge heatshield and the wing forward spar has exceeded 160°F. |
|  | The LO FUEL PRESS light illuminates to indicate the fuel pressure in the engine supply line is low below 5.3 psi. |  | The WING ANTI-ICE light illuminates to indicate the wing anti-ice bleed air temperature is too low below 220°F. |
|  | The W/S FAULT light illuminates to indicate the detection of a fault in the windshield anti-ice system. | | |

[illegible]

NOTES

Table 31-2. ANNUNCIATOR LIGHTS

| ANNUNCIATOR | DESCRIPTION |
|---|--|
|  | (XL only) Illumination occurs when the autopilot or yaw damper is manually disconnected by the crew or automatically disconnected due to malfunction. This annunciator is next to the L and R MASTER WARNING/MASTER CAUTION switchlights. XLS—AP and YD OFF annunciations appear in the L and R PFDs. |
|  | (XLS only) Steady illumination indicates the APU is operating and its generator is off line. |
|  | (XL and XLS) Steady illumination indicates the rudder bias heating blanket is heating. Flashing light indicates blanket sensor failure. Pressing the light causes steady illumination. This annunciator does not activate the MASTER CAUTION lights. |
|  | (XL and XLS) Switchlight indicates the No.1 or 2 flight director is controlling the autopilot. Press the switchlight to change flight directors. Switching flight directors with the autopilot engaged causes the autopilot to revert to basic pitch and heading hold modes. The flight director modes must be reselected. |
|  | (XL and XLS) Switchlight indicates the enhanced GPWS or TAWS warnings occur normally and the terrain map is displayed on the MFD. |
|  | (XL and XLS) When selected, inhibits the enhanced TAWS (EGPWS) warnings and the terrain map. Modes 1–7 remain active. |
|  | (XLS) Switchlight indicates that the TOO LOW FLAPS audio warning activates when the aircraft is below approximately 245 feet AGL, less than 160 KIAS, and landing flaps are not selected. |
|  | (XL and XLS) When pressed, the switch disarms or cancels the audio warning for landing with flaps less than 35°. The XL switchlight is labeled GPWS FLAP NORM and GPWS O'RIDE. The functions are the same. |
|  | (XLS) Switchlight indicates normal GLIDESLOPE audio warnings are active for deviations below the glideslope. The GLIDESLOPE warning sounds if the aircraft is below 1000 feet AGL, descending greater than 500 fpm, and below 1.3 dots. |
|  | (XLS) When pressed, disables the GLIDESLOPE audio warnings. The XL switchlight is labeled GPWS G/S and O'RIDE. The functions are the same. |
|  | (XLS) Pressing the switchlight initiates the TAWS system test. This test function is inhibited inflight. The XL switchlight is labeled GPWS TEST. The functions are the same. |

| ANNUNCIATOR | DESCRIPTION |
|---|--|
|  | (XL and XLS) Indicates normal operating mode (default position). Audio communications are active through the cockpit speakers and crew headsets. |
|  | Pressing the switchlight mutes all avionics audio through the cockpit speakers including TCAS and TAWS (EGPWS). The gear horn and NO TAKEOFF warnings are not inhibited. |
|  | (XL and XLS) (Optional) Steady illumination for an incoming HF radio call. |
|  | (XL and XLS) Indicates that cabin temperature is controlled from the cockpit temperature controller. When pressed, transfers the cabin temperature control to the cabin. |
|  | Illumination indicates pressure is available to the thrust reverser (pressure is sensed passed the isolation valve). Illumination is normal on ground during TR operation, but abnormal inflight. Illumination inflight causes the red MASTER WARNING lights to flash. |
|  | Illumination indicates the thrust reverser is unlocked. Illumination is normal on ground during TR operation, but abnormal inflight. Illumination inflight causes the red MASTER WARNING lights to flash. |
|  | Illumination of the white light indicates the thrust reverser is deployed. Illumination is normal on ground during TR operation, but abnormal inflight. |
|  | Illumination indicates high temperature is detected in the engine nacelle. 1. Closes the fuel F/W shutoff valve. 2. Closes the hydraulic F/W shutoff valve. 3. Deactivates the engine generator (opens the field relay). 4. Disarms the thrust reverser. 5. Arms the engine fire bottles. |
|  | Illumination of the white light indicates the respective engine fire bottle is armed. When pressed, the bottle discharges. The red ENGINE FIRE switchlight must be pressed to illuminate the BOTTLE ARMED lights. |
|  | Illumination indicates high temperature in the APU compartment. The APU automatically shuts down and the APU FAIL light illuminates. Pressing the red switchlight discharges the APU fire bottle. If the switchlight is not pressed, the fire bottle automatically discharges in 8 seconds. |
|  | Illumination indicates the APU relay is engaged during the APU start. Illumination also occurs when the APU generator participates in an engine start. |
|  | Illumination indicates the APU will not start due to a system malfunction (i.e., the APU fire bottle is low or the fire detection system is inoperative). If the APU is operating, the light indicates the APU is shutting down. Reasons for automatic shutdown include fire detected in the APU compartment or the fire bottle is low. Limitation: Starting the APU is prohibited whenever the APU FAIL light is illuminated. |
|  | Illumination indicates the APU start is complete and at operating speed (95% rpm + 4 seconds). The APU generator and bleed air can be selected after illumination. The light remains illuminated during APU operation. |
| | Illumination indicates APU bleed air valve (BAV) is other than closed. |

NOTES

| NO TAKEOFF | |
|--------------------|--|
| DESCRIPTION | <p>This message is displayed if the throttles are advanced beyond 43° TLA, airspeed less than 67 knots, and thrust reversers not deployed, the red NO TAKEOFF message will illuminate if one or more of the following conditions exist:</p> <ul style="list-style-type: none"> • Flaps not within takeoff range (<7° or >15°) • Elevator out of trim for takeoff • Horizontal stabilizer is out of takeoff positions <p>The red message also produces a voice aural “No Takeoff”.</p> |
| INHIBITS | LOPI, IN AIR |
| DEBOUNCE | Standard |

* The engine shutdown inhibit (ESDI) is not active in the air.

| EMERGENCY DESCENT | |
|--------------------|--|
| DESCRIPTION | The cabin altitude has exceeded 14,500 feet. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| | | |
|--------------------------|--|--|
| ENGINE FAILED L-R | | |
| DESCRIPTION | Either the left, right, or both engines have failed. | |
| INHIBITS | | |
| DEBOUNCE | Standard | |

| OIL PRESSURE LOW L-R | |
|----------------------|--|
| DESCRIPTION | This message is displayed when the oil prssure is low on either the left or right engine, or both engines. Due to transient allowances, the EICAS message and MASTER WARNING do not display until oil pressure is <20 PSI. |
| INHIBITS | LOPI, TOPI, ESDI, EFI, SIPI |
| DEBOUNCE | Standard |

| | |
|------------------------|--|
| ENGINE FIRE L-R | |
| DESCRIPTION | This message is displayed when the engine fire detection system has detected a fire. |
| INHIBITS | |
| DEBOUNCE | Standard, 1 Second |

| LAVATORY SMOKE DETECT | |
|-----------------------|---|
| DESCRIPTION | This message is displayed when smoke is detected in the lavatory. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

(*) = with exceptions

[illegible]

Table 31-4. AMBER EICAS MESSAGES

| ACM OVERTEMP | |
|--------------|--|
| DESCRIPTION | This message is displayed when the ACM has overheated. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| ADC SSEC MISCOMPARE | |
|---------------------|---|
| DESCRIPTION | This message is displayed when the pilot and copilot ADCs are on different SSECs. |
| INHIBITS | TOPI |
| DEBOUNCE | 10 Seconds |

| AFT BAGGAGE DOOR | |
|------------------|--|
| DESCRIPTION | This message is displayed when the baggage door is open. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| ANTISKID FAIL | |
|---------------|--|
| DESCRIPTION | This message is displayed when the antiskid system has failed or the LOW BRAKE PRESSURE message is displayed. |
| INHIBITS | POD, TOPI |
| DEBOUNCE | *20 Seconds |

| AOA HEAT FAIL | |
|---------------|---|
| DESCRIPTION | This message is displayed when the pitot/static heat switch is on and the AOA probe is not being heated. The advisory PITOT/STATIC COLD L-R-STBY message is used to alert the crew if the pitot/static switch is OFF. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| APU FAIL | |
|-------------|--|
| DESCRIPTION | This message is displayed when the APU has failed or the APU fire bottle is low. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| APU GENERATOR OFF | |
|-------------------|--|
| DESCRIPTION | This message is displayed when the APU is on and the APU generator relay is open. The message is amber if the APU generator switch is selected on. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| APU ON | |
|-------------|---|
| DESCRIPTION | This message indicates the APU is on above 30,000 feet. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| BATTERY DOOR | |
|--------------|--|
| DESCRIPTION | This message is displayed when the battery door is open. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| BLEED AIR OVERTEMP L-R | |
|------------------------|---|
| DESCRIPTION | This message is displayed when the supply bleed air from the engine is too hot. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | 20 seconds |

| CABIN AIR DUCT OVERTEMP | |
|-------------------------|---|
| DESCRIPTION | This message is displayed when the supply air in the cabin air duct is too hot. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | 20 seconds |

| CABIN DOOR | |
|-------------|--|
| DESCRIPTION | This message is displayed when the cabin door is open. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| CABIN DOOR SEAL | |
|-----------------|---|
| DESCRIPTION | This message is displayed when the pressure in the cabin door seal is less than 5 PSI |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| COCKPIT AIR DUCT OVERTEMP | |
|---------------------------|---|
| DESCRIPTION | This message is displayed when the supply air in the cockpit air duct is too hot. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

NOTES

(*) = with exceptions

Table 31-4. AMBER EICAS MESSAGES (CONT)

| FUEL FILTER BYPASS L-R | |
|------------------------|--|
| DESCRIPTION | This message is displayed when the fuel filter impending bypass is true. (The fuel filter on one or both engines has become clogged and has been bypassed) |
| INHIBITS | LOPI, TOPI, *ESDI, SIPI |
| DEBOUNCE | Standard |

| FUEL GAUGE L-R | |
|----------------|--|
| DESCRIPTION | This message is displayed when there is a fault in the fuel quantity indicating system, as determined by the fuel quantity signal conditioner. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| FUEL LEVEL LOW L-R | |
|--------------------|--|
| DESCRIPTION | This message is displayed when the fuel level in the fuel tank is low as determined by a float switch. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | *34 Seconds |

| FUEL PRESSURE LOW L-R | |
|-----------------------|--|
| DESCRIPTION | This message is displayed when the fuel pressure is low, and the respective engine is running. |
| INHIBITS | LOPI, TOPI, ESDI, SIPI |
| DEBOUNCE | Standard |

| GROUND IDLE L-R | |
|-----------------|--|
| DESCRIPTION | This message is displayed if a FADEC failure should result in ground idle mode in air. |
| INHIBITS | TOPI |
| DEBOUNCE | 1 Second |

| HYDRAULIC FLOW LOW L-R | |
|------------------------|--|
| DESCRIPTION | This message is displayed when the hydraulic flow is low after engine start. |
| INHIBITS | LOPI, TOPI, *ESDI, SIPI |
| DEBOUNCE | *5 Seconds |

* The engine shutdown inhibit (ESDI) is not active in the air.

| HYDRAULIC PRESSURE | |
|--------------------|---|
| DESCRIPTION | This message is displayed when hydraulic system has remained pressurized for more than 40 seconds in the air. |
| INHIBITS | *LOPI, *TOPI |
| DEBOUNCE | *40 Seconds |

| HYDRAULIC FLUID LEVEL LOW | |
|---------------------------|---|
| DESCRIPTION | This message is displayed when the hydraulic fluid level in the reservoir is low. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| IAPS FAULT | |
|-------------|---|
| DESCRIPTION | This message is displayed when the IEC monitor has detected a fault in the environmental control of the IAPS. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | 1 Second |

| IAPS OVERTEMP | |
|---------------|--|
| DESCRIPTION | This message is displayed when the power supply has overheated and is entering the shutdown cycle. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | 15 seconds |

| J-BOX CURRENT LIMITER | |
|-----------------------|--|
| DESCRIPTION | This message is displayed when one of the two 225-Amp limiters in the power J-Box have opened. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| J-BOX START CB | |
|----------------|--|
| DESCRIPTION | This message is displayed when one of four breakers for the start cards has tripped. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| LAVATORY DOOR | |
|---------------|--|
| DESCRIPTION | This message is displayed when the lavatory door is closed and the aircraft is on the ground, or flaps are out of 0° position. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| LOW BRAKE PRESSURE | |
|--------------------|--|
| DESCRIPTION | This message is displayed when the brake pressure is low and the right main gear is down and locked. |
| INHIBITS | POD |
| DEBOUNCE | *20 Seconds |

| NOSE DOOR | |
|-------------|--|
| DESCRIPTION | This message is displayed when either nose door is open. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| OIL FILTER BYPASS L-R | |
|-----------------------|--|
| DESCRIPTION | This message is displayed when one, or both of the oil filters are clogged and have become bypassed. |
| INHIBITS | LOPI, TOPI, ESDI |
| DEBOUNCE | Standard |

NOTES

(*) = with exceptions

NOTES

| TAIL DE-ICE FAIL L-R | |
|----------------------|--|
| DESCRIPTION | This message is displayed when a failure of the tail de-icing system is detected by the Tail De-Ice PC Card. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| TAILCONE ACC DOOR | |
|--------------------|--|
| DESCRIPTION | This message is displayed when the tailcone access door is not properly secured. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| TAWS BASIC FAIL | |
|--------------------|---|
| DESCRIPTION | This message is displayed when the radio altimeter based ground proximity modes of the TAWS function have failed, and the TAWS SYSTEM FAIL message is not active. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | 1 Second |

| TAWS SYSTEM FAIL | |
|--------------------|--|
| DESCRIPTION | This message is displayed when all TAWS functions (ground prox, windshear, and terrain) have failed. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | 1 Second |

| TAWS TERR FAIL | |
|--------------------|---|
| DESCRIPTION | This message is displayed when the enhanced modes of the TAWS function have failed, and the TAWS SYSTEM FAIL message is not active. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | 1 Second |

* The message is also inhibited by an engine and/or APU start on the ground.

(*) = with exceptions

Table 31-4. AMBER EICAS MESSAGES (CONT)

| TAWS TERR NOT AVAIL | |
|---------------------|--|
| DESCRIPTION | This message is displayed when the GPS data received by the TAWS unit is not within required accuracy, or GPS data is not available. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | 1 Second |

| TAWS WINDSHEAR FAIL | |
|---------------------|--|
| DESCRIPTION | This message is displayed when the windshear modes of the TAWS funtion have failed, and the TAWS SYSTEM FAIL message is not active.. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | 1 Second |

| WINDSHIELD HEAT INOP L-R | |
|--------------------------|--|
| DESCRIPTION | This message is displayed when the controller has detected a failure |
| INHIBITS | LOPI, TOPI, *ESDI, SIPI |
| DEBOUNCE | *8 Seconds |

* The 8-second debounce and engine shutdown are removed by windshield rotary test. The engine shutdown inhibit (ESDI) is also removed in the air.

| WINDSHIELD OVERTEMP L-R | |
|-------------------------|---|
| DESCRIPTION | This message is displayed when the windshield controller has detected an overheat situation.. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | *4 Seconds |

* The 4-seconds debounce is removed by indshield test.

| WING ANTI-ICE COLD L-R | |
|------------------------|---|
| DESCRIPTION | This message is displayed when WING ANTI-ICE or CROSSFLOW is selected ON, but too much time has elapsed before the wing has reached sufficient temperature, or wing anti-ice surfaces warmed up, but have cooled off again. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| WING ANTI-ICE OVERTEMP L-R | |
|----------------------------|---|
| DESCRIPTION | This message is displayed when one of the 6 over-temperature switches (3 switches in each wing) gets too hot. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

NOTES

(*) = with exceptions

Table 31-5. WHITE EICAS MESSAGES (CONT)

| NO TAKEOFF | |
|-------------|---|
| DESCRIPTION | On the ground, the WHITE NO TAKEOFF message will illuminate if one or more of the following conditions exist: <ul style="list-style-type: none">• Flaps not within takeoff range (<7° or >15°)• Elevator out of trim for takeoff• Horizontal Stabilizer is out of takeoff position• Speed Brakes are out of takeoff position |
| INHIBITS | LOPI, In Air |
| DEBOUNCE | Standard |

| PITOT/STATIC COLD L-R-STBY | |
|----------------------------|--|
| DESCRIPTION | The WHITE message is displayed on ground when the pitot/static switch is selected OFF. |
| INHIBITS | LOPI, TOPI, *SIPI |
| DEBOUNCE | Standard |

| RUDDER BIAS COLD | |
|------------------|---|
| DESCRIPTION | This message is displayed while the rudder bias heater system is cold and it is not failed. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| SELCAL DATALINK | |
|-----------------|---|
| DESCRIPTION | This message is displayed when the SELCAL code is received on the datalink. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | 1 Second |

| SELCAL HF 1-2 VHF 1-2-3 | |
|-------------------------|--|
| DESCRIPTION | SELCAL is a system that monitors the HF and VHF COMM radio for an aircraft specific code sequence. This message is displayed when the code for that particular aircraft is received. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | 1 Second |

| SPEED BRAKES | |
|--------------|--|
| DESCRIPTION | This message is displayed when either speed brake panel is extended. |
| INHIBITS | TOPI |
| DEBOUNCE | Standard |

| TAIL DE-ICE PRESS ON L-R | |
|--------------------------|---|
| DESCRIPTION | This message is displayed when there is air pressure in one or both tail deice boots. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

| WING ANTI-ICE COLD L-R | |
|------------------------|--|
| DESCRIPTION | This message is displayed when wing anti-ice or crossflow is selected ON, but one or both surfaces have not warmed up yet. |
| INHIBITS | LOPI, TOPI |
| DEBOUNCE | Standard |

NOTES

(*) = with exceptions

ROTARY TEST KNOB (XL/XLS)

This section describes the indications in each detent position of the rotary TEST knob. Certain indications must be present to verify a satisfactory self-test before proceeding to the next position. Following is a brief description of each of these indications.

Off Position—With the rotary knob in the OFF position, the red light above the rotary knob extinguishes and the test system is inoperative.

NOTE

The red light above the rotary TEST knob illuminates for all the other test positions, including the SPARE position.

FIRE WARN Position—With the rotary TEST knob in the FIRE WARN position, the LH–RH ENGINE FIRE lights on the fire tray illuminate.

LDG GEAR Position—With the rotary TEST knob in the LDG GEAR position, the green LH, RH, and NO lights illuminate, The red GEAR UNLOCK light illuminates, the gear warning horn sounds.

BATT TEMP Position—With the rotary TEST knob in the BATT TEMP position, the red BATT O’TEMP and >160° annunciator lights flash, The battery temperature gauge indicates 160°F, The MASTER WARNING light flashes. Press the MASTER WARNING light and verify the light extinguishes.

STICK SHAKER Position—The STICK SHAKER fires immediately on pilot and copilot columns. The angle of attack indicator needle moves to the top of the RED band.

T/REV—The left and right, ARM, UNLOCK, and DEPLOY lights illuminate steady. The MASTER WARNING RESET switchlights flash (approximately two flashes per second). Press MASTER WARNING RESET and verify light extinguishes.

W/S TEMP—With windshield heat selected on, the L–R W/S O’HEAT annunciator illuminates steady for 3 to 4 seconds then extinguish.

NOTE

If windshield heat is selected on with the engines shut down, W/S FAULT illuminates because the AC alternator is not supplying power.

OVERSPEED—The pulsating OVERSPEED audible warning horn sounds. The MADC output reverts to Functional Test Mode and PFD1/2 indicates 265 KIAS, Mach 0.4, 5,000 feet altitude and a vertical speed of 2,000 ft/min.

ANTI-SKID—With the antiskid switch on, the ANTI-SKID INOP annunciators flash for 3 to 4 seconds then extinguish. The MASTER CAUTION RESET switchlights illuminate steady during the self-test.

ANNU—Turn AVIONIC PWR switch to ON. All annunciator panel legends illuminate, and altitude alert warning audio horn sounds.

The MASTER WARNING lights and MASTER CAUTION light illuminate steady and are non-cancelable.

Both red turbine overspeed lights flash.

The engine instrument LCDs show steady 8s.

The AP OFF and YD OFF annunciators illuminate steady.

The Flight Director Mode Selector (FDMS) buttons illuminate left to right and then remain steady.

The annunciators to the right of the FDMS panel illuminate steady. They are as follows, (but may vary depending on which options are installed):

- 1. FD/AP PFD 1, FD/AP PFD 2
- 2. TERR NORM, TERR INHIB
- 3. GPWS FLAP NORM, GPWS FLAP OVRD
- 4. GPWS G/S, CANCELLED
- 5. GPWS TEST
- 6. PHONE CALL

All A/P control panel lights illuminate steady.

The green A/C ON light above the A/C switch illuminates steady.

A pulsating aural horn, which is a combination of the following 3 inputs sounds:

- 1. Autopilot disconnect tone (steady).
- 2. Altitude alert tone (steady).
- 3. Phone call tone (pulsating and becomes steady when the PHONE CALL button is depressed).

AVN

Turn AVIONIC PWR switch to ON.

The MASTER CAUTION RESET switchlight illuminates steady and is cancelable.

The Flight Director Mode Selector (FDMS) buttons illuminates left to right and then remain steady.

All A/P control panel lights illuminate steady.

After a short delay the following annunciators flash indicating a successful self-test:

- 1. AP PITCH MISTRIM
- 2. AP ROLL MISTRIM
- 3. RADOME FAN
- 4. CHECK PFD1
- 5. CHECK PFD2

The annunciators to the right of the FDMS panel illuminate steady. They are as follows (but may vary depending on which options are installed):

- 1. FD/AP PFD 1, FD/AP PFD 2
- 2. TERR NORM, TERR INHIB
- 3. GPWS FLAP NORM, GPWS FLAP OVRD
- 4. GPWS G/S, CANCELLED
- 5. GPWS TEST
- 6. PHONE CALL

The AP OFF and YD OFF annunciators illuminate steady.

A pulsating aural horn, which is a combination of the following 3 inputs sound:

- 1. Autopilot disconnect tone (steady).
- 2. Altitude alert tone (steady).
- 3. Phone call tone (pulsating and becomes steady when the PHONE CALL button is depressed).

Spare

This position is a spare, and does not activate any system.

After the test is complete, rotate the test knob to OFF.

[illegible]

CHAPTER 32

LANDING GEAR

32



INTRODUCTION

This chapter presents the Landing Gear and brake systems for the Citation 560XL/XLS/XLS+ aircraft. General maintenance considerations are included, accompanied by functional and operational checks. References for this chapter and further specific information can be found in Chapters 5—“Time Limits/Maintenance Checks,” Chapter 12—“Servicing,” and Chapter 32—“Landing Gear,” of the *Aircraft Maintenance Manual (AMM)*.

GENERAL

The landing, gear system for the 560XL/ XLS/XLS+ is controlled electrically and hydraulically actuated. The nose gear assembly consists of a single wheel assembly and an oil-over-air (nitrogen) strut; while the main gear assemblies also consist of a single wheel assembly, but an air-over-oil strut.


The nose gear tire is the chined type for water and slush deflection.

The main gear doors are mechanically linked to the main gear trunnions, so they extend and retract with the main gear and require no separate actuators. The nose gear has three doors. The aft “spade” door is linked to the nose gear trunnion, so it extends and retracts with

the gear. The two forward “side” doors for the nose gear are actuated through a system of linked rods and torque tubes, so they are mechanically opened and closed as the nose gear extends and retracts.

The actuators for each gear incorporate internal mechanical downlocks to hold the gear in the extended position. The gear is held retracted by mechanical uplocks that are spring-loaded to lock. They are hydraulically released.

The main gear is equipped with hydraulically actuated disc brakes. An emergency (pneumatic) braking system is provided for use when hydraulic braking fails. Brake antiskid control prevents wheel skidding on wet, dry or icy runways after minimum wheel spin is attained.







Figure 32-2. Landing Gear Retracting



LEGEND

- STATIC FLOW
- RETURN PRESSURE
- PRESSURE (MAIN)
- NITROGEN PRESSURE


CONDITION

GEAR SELECTED—DOWN
GEAR IN TRANSIT

NOTES

Notes section with horizontal lines for recording information.

Figure 32-3. Landing Gear Extending



LEGEND


- STATIC FLOW
- RETURN PRESSURE
- PRESSURE (MAIN)
- NITROGEN PRESSURE

CONDITION

EMERGENCY GEAR
BLOW-DOWN HANDLE—PULLED
GEAR EXTENDED


NOTES

Figure 32-4. Landing Gear Emergency Extension



NOTES


Figure 32-5. Landing Gear Control and Landing Gear Warning (Retracting) (XL/XLS)



NOTES


| | | |
|--|--|--|
| | | |
| | | |
| | | |
| | | |
| | | |

Figure 32-6. Landing Gear Control and Landing Gear Warning (Retracted) (XL/XLS)



NOTES

Figure 32-7. Landing Gear Control and Landing Gear Warning (Extending with Nose Gear Down and Locked) (XL/XLS)



NOTES

Figure 32-8. Landing Gear Control and Landing Gear Warning (Extended) (XL/XLS)

NOTES




Figure 32-9. Landing Gear Electrical—Down and Locked (XLS+)

NOTES




Figure 32-10. Landing Gear Electrical—In Transit Up (XLS+)

NOTES




Figure 32-11. Landing Gear Electrical—Up and Locked (XLS+)

CHAPTER 33 LIGHTS

33



INTRODUCTION

This chapter describes those units and components which provide for external and internal illumination on the Citation XL/XLS/XLS+. This chapter does not include lights for individual systems. The information in this chapter must be used in conjunction with Citation XL/XLS/XLS+ Wiring Diagram Manual to correlate data required to maintain the lighting systems that illuminate the interior and exterior of the airplane.

GENERAL

The Citation XL/XLS/XLS+ lighting consists of four major groups: interior, emergency, exterior, and tailcone lighting. Switches and rheostats control all lighting. Separate circuit breakers in the cockpit or tailcone J-box protect the system.

Interior lighting consists of direct, indirect, fluorescent, and incandescent lighting for the cockpit and cabin.

Emergency lighting is a separate independent system that provides automatic illumination in case of main DC electrical power failure, a +5G impact, or illumination of passenger safety lights.

Exterior lighting consists of lights for landing, taxi, recognition, anticollision, wing inspection, tail flood, and ground recognition beacon.

Tailcone lighting consists of interior lighting in the tailcone and baggage compartment areas.

The Citation XLS/XLS+ incorporate light emitting diode (LED) lights to replace incandescent bulbs installed on the XL. LED lights operate at reduced temperatures that increase the life of the light assembly and reduce the possibility of heat damage to adjacent objects.

The following is a list of Citation XLS+ LED light assemblies:


- Accent lights in refreshment storage area
- Aft vanity lights (indirect lighting and furniture lighting) (halogen over toilet)

- Cabin divider lamps
- Cabin drop aisle emergency lights
- Cabin indirect lighting
- Emergency egress lights (overwing) (units 5560 and subsequent)
- Emergency exit signs
- Navigation light tail
- All other panel lights, i.e., vanity switch panel control, entry door light panel control

The XLS+ also incorporates LED anticollision lights, navigation lights, ground recognition lights, and AUX panel lights.



LANDING/REC/TAXI LIGHTS PANEL



The diagram illustrates the rear panel of the vehicle, which includes the following components:


- AUX PANEL LIGHT**: A circular light with a "DIM" and "OFF" label and an arrow pointing to the center.
- MAP LIGHT**: A circular light with a "DIM" and "OFF" label and an arrow pointing to the center.
- BATTERY DISCONNECT**: A red rectangular switch.
- ELT ACTIVATED WHEN LIT**: A yellow circular light.
- ON**: A toggle switch.
- TEST/RESET SELECT ON**: A label for the toggle switch.
- WAIT 1 SECOND SELECT ARM**: A label for the toggle switch.
- EMERGENCY USE ONLY**: Labels on the left and right sides of the emergency switch area.
- INTERIOR MASTER OFF**: A red rectangular switch.

The diagram illustrates the cockpit control panel with the following components and their states:


- DC POWER:**
 - L GEN:** Switch is in the **ON** position.
 - BATT:** Switch is in the **ON** position.
 - R GEN:** Switch is in the **ON** position.
- AVIONIC POWER:** Switch is in the **ON** position.
- RESET:** Two reset buttons are present, one for the left engine and one for the right engine.
- EMER:** Emergency stop button.
- EMER LTS:** Emergency lights switch, currently in the **ARM** position.
- ENG DATA SCAN:** Button for engine data scanning.
- ECC:** Engine control switch, currently in the **AUTO** position.
- PARK BRAKE:** Located at the bottom right, labeled **PARK BRAKE – PULL**.

Figure 33-1. Lighting Control (XL/XLS)


[illegible]



LIGHT SWITCH PANEL




DIMMING CONTROL PANEL



WING INSPECTION LIGHTS PANEL



AUXILIARY LIGHTS PANEL



EMERGENCY LIGHTS PANEL

NOTES

Notes section with 10 horizontal lines for recording information.

Figure 33-2. Lighting Controls (XLS+)

NOTES




Figure 33-4. Exterior Lights (XL/XLS/XLS+)

NOTES

33

CHAPTER 34 NAVIGATION



34

INTRODUCTION

The navigation section describes units and components which provide aircraft navigational information. This includes pitot static, flight director, VOR and other navigational systems and indicators. Each Citation XL/XLS/XLS+ aircraft is delivered with complete *Avionics Wiring Diagrams* specifically prepared for that serial number aircraft.

GENERAL

Navigational information for the Citation XL/XLS is provided by pitot-static systems, Honeywell micro air data computer (MADC), radio altimeters, total air temperature (TOT) probes, angle of attack (AOA) system and magnetic compass. Electronic flight information system (EFIS), attitude heading reference system (AHRS), controllers, localizer, glideslope and marker beacon, radar, ground proximity

warning system (GPWS), traffic alert and collision avoidance system (TCAS), global positioning system, and flight management systems (FMS) give the crew navigation information for flights. This information displays on either the primary or multifunction display screens and instruments in the cockpit.




Figure 34-1. Citation XL Pitot-Static Overview Block Diagram

NOTES




Figure 34-2. Navigation System (XLS)




Figure 34-3. Primus 1000 Avionics Diagram (XLS)

34

[illegible]




Figure 34-4. Proline 21 Avionics System Diagram (XLS+)

NOTES

[illegible]

CHAPTER 35 OXYGEN



35

INTRODUCTION

This chapter describes the oxygen system found on the Citation 560 XL/XLS/XLS+ aircraft. In addition to system descriptions, emphasis has been given to maintenance and servicing precautions, along with functional testing. References for this chapter and further specific information can be found in Chapters 5—“Time Limits/Maintenance Checks,” Chapter 12—“Servicing,” and Chapter 35—“Oxygen,” of the *Aircraft Maintenance Manual (AMM)*.

GENERAL

The oxygen system consists of the crew oxygen system and the passenger oxygen system. Oxygen is available to the crew at all times and is available to the passengers either automatically (above a predetermined altitude) or manually (at any altitude by a cockpit control). The oxygen system primarily provides emergency oxygen.

OXYGEN SYSTEM DESCRIPTION

The oxygen system consists of:


- Pilot and copilot masks
- Dual passenger oxygen dropout boxes
- Altitude sensing pressure switch

- Composite oxygen bottle with a pressure regulator
 - 50 cubic foot—SNs 5001 through 5619
 - 77 cubic foot—SNs 5620 and Subsequent
- Oxygen pressure gauge
- Overboard pressure relief valve
- Oxygen filler valve
- Passenger oxygen control valve
- Necessary plumbing

Oxygen system flow schematics are provided in the crew and passenger oxygen system sections.

The oxygen system has a high-pressure and low-pressure side. The oxygen is stored in the high-pressure side in a composite 50 or 77 cubic foot bottle just to the right of the wheelwell in the nose compartment. The low-pressure side is controlled by a pressure regulator that attaches directly to the oxygen cylinder. The regulator is turned ON or OFF with the attached control handle. With the handle turned to the OFF position, the regulator functions as a shutoff valve while venting the low-pressure side of the system internally through the regulator. With the handle turned to the ON position and safety wired, the regulator provides a constant 70 ± 10 psi (482 ± 69 kPa) pressure to the low-pressure side of the system. The low-pressure side supplies oxygen to the crew outlets and to oxygen dropout boxes in the cabin.

35



The low-pressure side of the system of the system is split into two subsystems: one for the cabin and one for the cockpit. A passenger oxygen control valve separates the two halves of the system. Oxygen is always available to the crew through the crew distribution lines, but is blocked from entering the passenger system by the passenger oxygen control valve. The passenger oxygen control valve is a three-way, manual/solenoid-operated valve that has three positions: OFF, AUTO, and ON. Typically the valve is left in the AUTO position. With the valve in the AUTO position, when the cabin altitude increases to a pressure altitude of $14,500 \pm 500$ feet (4420 ± 152 m), the pressure altitude switch applies electrical power to the solenoid of the passenger oxygen control valve, opening the passenger oxygen control valve. When the passenger oxygen control valve opens, it allows 70 ± 10 psi (482 ± 69 kPa) of pressure to flow into the cabin oxygen system. This pressure is sufficient to deploy the doors on the oxygen dropout boxes and drop the passenger masks. In the event of a failure or at the discretion of the crew, the passenger system can be manually actuated by turning the passenger oxygen control valve to the ON position. The ON position manually opens the passenger oxygen control valve, deploying the doors on the oxygen dropout boxes and releasing the passenger masks. After deployment of the passenger masks, oxygen flow to the passenger is initiated by pulling the lanyard cord attached to the passenger mask, which in turn pulls the pintle pin. The control of oxygen flow into the passenger masks is achieved by a precision orifice between the supply line and the mask. When the passenger oxygen control valve is positioned to OFF, only the crew's oxygen system is operational and no oxygen flows to the cabin and the passenger masks.

NOTES

Figure 35-1. Oxygen System—Normal

NOTES




Figure 35-2. Oxygen System—OFF

NOTES




Figure 35-3. Oxygen System—ON

Notes section with horizontal lines for recording information.

CHAPTER 36

PNEUMATIC SYSTEM



36

INTRODUCTION

This chapter presents the pneumatic system for the Citation XL/XLS/XLS+ aircraft, with discussion primarily limited to the delivery and control of bleed air into the tail cone area and the service air system. Each bleed-air user system is covered in detail within the appropriate chapters of this training manual. General maintenance considerations are included, with an introduction to functional and operational checks. References for this chapter and further specific information regarding components or operation can be found in Chapter 5—“Time Limits/Maintenance Checks,” Chapter 12—“Servicing,” and Chapter 36—“Pneumatics” in the *Aircraft Maintenance Manual (AMM)*.

GENERAL

This section describes the extraction, control, and distribution of bleed air from the engines to the connecting components of systems that utilize bleed air and service air for temperature and/or pressure purposes.

This section provides description and maintenance information on the pneumatic distribution system components in the nacelle, pylon, and tail cone. This includes hardware required to duct the bleed air through the pylon into the tail cone, but does not include the engine inlet anti-ice system, the wing anti-ice system or the air-conditioning system.


Pneumatics Description

- Airplane systems that utilize engine bleed air and service air are as follows:
- Air-conditioning, cabin pressurization, and cabin temperature control systems
 - Wing leading edge anti-ice system
 - Horizontal stabilizer deice boot system
 - Engine inlet anti-ice system

- Cabin door primary seal
- Cabin door acoustic seal
- Throttle detent system
- Rudder bias system

Bleed air is extracted from the engine at all times when the engine is operating. Usage of the bleed air depends on the position of the control valve of individual systems using bleed air.

36



NOTES

Figure 36-1. Bleed Air Precooler Overview—Units 5001-5500

NOTES




Figure 36-2. LH Bleed Air Precooler Overview – Units 5501-5616, 5618-6000 (Right Side Typical)







Figure 36-3. LH Bleed Air Precooler Overview – Units 5617, 6001 and Subsequent (Right Side Typical)



NOTES




Figure 36-4. Bleed Air System—ON

36

CHAPTER 38

WATER/WASTE



38

INTRODUCTION

This chapter provides information on the water/waste system on the Citation XL/XLS/XLS+ aircraft. Information includes fixed units and components that store and deliver fresh water for use, and fixed components that store and furnish a means of removal of water and waste. Interior arrangement and options may cause variation in equipment description and installation.

GENERAL


Potable water provisions are made available through the forward refreshment center in the left forward cabin compartment between FS 161.54 and FS 183.55 and the aft vanity/closet installation in the aft end of the cabin compartment at FS 370.60.

Wash water is available through a wash basin in the aft/vanity closet installation at the aft end of the cabin compartment at FS 370.60.

Waste disposal is accomplished with a flush-type toilet in the aft cabin on the left side of the aircraft. The flush toilet is self-contained to the extent that it requires only a 28 VDC electrical power source for operation.

CHAPTER 45

CENTRAL MAINTENANCE SYSTEM



45

INTRODUCTION

This chapter describes the central maintenance system which is an integrated part of the Collins Pro Line 21 Avionics Suite on the XLS+ aircraft. Information is provided on the procedures to look at the maintenance messages available through the Collins Pro Line 21 system.

GENERAL

The Collins Pro Line 21 system messages are shown directly on the multifunction displays (MFDs). For information on access and use of the maintenance diagnostic computer (MDC) refer to “Collins Maintenance Diagnostic Computer System—Description and Operation” in the *Aircraft Maintenance Manual (AMM)*.

The Collins MDC system monitors many of the aircraft components to find failures, isolate faults, and give you historical fault data.

The Collins MDC system monitors the data that it receives from the left and right IOC-4110 input/output concentrator (IOC) Modules in

the IAPS card cage. The diagnostic data is sent from the IOCs to the MDC on the left and right IOC-4 high-speed ARINC 429 buses.

The MDC sends the diagnostic data through the MDC-2 high-speed ARINC 429 bus to be shown on the MFD (Figure 45-1). You can see this diagnostic data and download diagnostic reports from the file server unit (FSU).


The cursor control panel (CCP) gives you the controls to get access to the Maintenance Main Menu for the MDC.

There is also a live data view capability that displays airframe PCB I/O data to indicate current state, FADEC operating parameters, and



switch/sensor values. The switch/sensor values include flap position as well as control surface trim position in support of auto rig functionality for FDR control surface position sensors.

The DBU-5000 is a data loader and interface for the LRUs on the aircraft and is located in the pedestal below the right CCP (Figure 45-1). The DBU is used to load the FMS, MDC, FSU databases and software through the Ethernet port on the FSU-5010. Removable storage media (e.g. USB memory device) is used to transfer files to the LRUs.

The MDC monitors the data that it receives from the left and right IOC-4110 IOC modules in the IAPS card



MFD



CCP

DBU

NOTES

Figure 45-1. Collins MDC System Components

OPERATION

To access the maintenance menu apply external power to the aircraft and turn on aircraft power and the avionics. Allow approximately 5 minutes for the system to stabilize before proceeding.

Push the DATABASE button on the CCP followed by the UPR MENU or LWR MENU button on the CCP to show the DATABASE MENU (Figure 45-1). Turn the MENU ADV (outer) knob on the CCP to highlight the MAINTENANCE MAIN MENU. Push the PUSH SELECT (inner) button on the CCP to get access to the MAINTENANCE MAIN MENU page.

The MAINTENANCE MAIN MENU contains the following pages :

CURRENT FAULTS—Gives advanced diagnostics of the component with the fault. The information contained in the current faults page includes:

- DETAILED DIAGNOSTIC DATA—Displays active data words and status conditions, as well as the diagnostic words that caused the fault message to be recorded. The DATA USED TO DETERMINE MESSAGE display shows all the diagnostic words that were used in the MDC logic equation.
- The LRU DIAGNOSTIC DATA fields show the octal label and diagnostic word received from the effected LRU and a maximum of ten diagnostic words can be shown. The field shows dashed lines if the associated word is not received. Each diagnostic word contains useful information that may simplify troubleshooting. The diagnostic words can be shown in either binary or hexadecimal format.

CURRENT SERVICE MESSAGES—Shows events or conditions which may not be faults but could be of interest to maintenance.

AIRCRAFT HISTORY—Gives the fault history and flight leg summary that includes fault history, service message history, engine trend history, and flight leg summary.

LRU TEST—Provides discrete testing capability for individual LRUs.

LRU RIGGING—Accesses specific rigging information for selected LRU.

SYSTEM PARAMETERS—Shows maintenance or information aircraft system parameters on a real-time basis.

ATA INDEX—Shows a list of the ATA chapters for the LRUs on the aircraft.

LRU INDEX/OPERATIONS—List of aircraft LRUs.

MDC SETUP—Provides setup control of some MDC parameters.

Examples include the aircraft identification code and the aircraft clock, configuration control, and the file load function that allows files from a database, including user checklists, to be loaded from a disk.

CONFIGURATION DATA—Shows the configuration strapping unit configuration.

REPORT DOWNLOAD—Provides the ability to download MDC report files via the DBU.

There is also a separate flight control system (FCS) DIAGNOSTICS page that allows troubleshooting of autopilot and yaw damper failures. Access to the FCS DIAGNOSTICS page is obtained from the DATABASE MENU.


NOTES

NOTES

45

CHAPTER 49

AIRBORNE AUXILIARY POWER



49

INTRODUCTION

This chapter describes the onboard auxiliary power unit (APU) for the 560XL/XLS/XLS+, which generates to provide auxiliary bleed air and auxiliary electrical power. Information is provided for the major APU sections, major systems, fire detection and extinguishing. References for this chapter and further specific information can be found in Chapter 5—“Time Limits/Maintenance Checks,” Chapter 12—“Servicing,” and Chapter 49—“Airborne Auxiliary Power,” of the *Aircraft Maintenance Manual (AMM)*.

GENERAL

The APU is an AlliedSignal Aerospace Inc./Honeywell model RE100 (XL). It is in a containment box in the tail cone of the aircraft. The air inlet for the APU is on the upper right corner of the access door. Exhaust exits through a vent on the right side of the tail cone, forward and slightly below the horizontal stabilizer leading edge. It is a fully-automatic, constant-speed, gas turbine engine, that provides both electrical and pneumatic (bleed air) power while on the ground or in the air.

The APU is certified for ground and in-flight use. Maximum altitude is 20,000 feet for starting and 30,000 feet during operation. An amber APU ON crew alerting system (CAS) message appears if the APU is on above 30,000 feet.

Subsystems include:

- Lubrication
- Fuel
- Ignition
- Control/indicating
- Electrical
- Pneumatics

A fire detection and extinguishing system (attached to the APU) is monitored and controlled in the cockpit. Electrical power is

supplied (using shaft power) by the auxiliary generator mounted to the accessory gearbox.

Pneumatic and shaft power may be supplied simultaneously or independently. When both types of power are demanded, the shaft power has priority. Selector switches in the flight crew compartment initiate all load requirements. APU is said to be at idle when running at 100% speed with no power being extracted. When loads are exerted on APU, fuel flow increases maintaining constant speed of 100%.

Protective devices within the APU engine control and monitor lubricating oil pressure and temperature, turbine exhaust gas temperature, powerplant overspeed and underspeed, and sequence failure.

[illegible]

NOTES





Figure 49-2. APU Pneumatic System Overview



49-4

CHAPTER 51-57 STRUCTURES



51-57

INTRODUCTION

This chapter provides a description of the aircraft structures, doors, fuselage, nacelles, pylons, stabilizers, windows, and wings on the Citation XL/XLS/XLS+ aircraft.


GENERAL

This chapter is divided into seven sections briefly described below. For locating subjects within the sections, refer to the Table of Contents at the beginning of this chapter.

This chapter provides an overall description of the nose, cabin, fuselage, tail cone, empennage, and wing.

The Doors section provides a general description of the cabin entry door, emergency exit door, baggage door, nose compartment and service doors, auxiliary power unit door, and the door warning system.

The Fuselage section describes the structural compartments for equipment, flight crew, passengers, and baggage. Included are the main frame, nose radome, plates/ skin, auxiliary structure, and aerodynamic fairings.



NOTES

51-57


| | | |
|--|--|--|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

Figure 51-1. Fuselage Sections

NOTES

51-57

CHAPTER 71-80 POWERPLANT



INTRODUCTION

This chapter describes powerplants installed on the Citation XL/XLS. Included are descriptions and operation of the major sections, secondary air systems, engine anti-ice system, interstage turbine temperature (ITT) indicating system, oil system, ignition system, fuel system, instrument system, synchronizing system, and thrust reversers. General maintenance considerations are included with an introduction to functional checks for fault analysis. Powerplant limitations are listed. The values listed are intended for training and illustrative purposes. References for this chapter and further specific information can be found in Chapter 5—“Time Limits/Maintenance Checks,” Chapter 12—“Servicing,” Chapter 54—“Nacelles/Pylons,” Chapter 71—“Powerplant,” Chapter 73—“Engine Fuel Control,” Chapter 74—“Ignition,” Chapter 76—“Engine Controls,” Chapter 77—“Engine Indicating,” Chapter 78—“Exhaust,” and Chapter 79—“Oil” of the Citation XL/XLS *Aircraft Maintenance Manual (AMM)*.

GENERAL

The 560XL series of aircraft are powered by two the Pratt and Whitney 545 series engines. The PW545 is a low-noise, light-weight, high-bypass ratio, twinpool turbofan engine.

The PW545A engine is installed on aircraft -5001 through 5500 and has a maximum rated thrust on an 83°F (28.3°C) day at sea level of 3,804 pounds (1,725 kg).

The PW545B engine is installed on aircraft -5501 through 6000 and has a maximum rated thrust on an 83°F (28.3°C) day at sea level for each engine is 4,119 pounds (1,794 kg).

The PW545C engine is installed on aircraft -6001 and subsequent and the maximum rated thrust on an 77°F (25°C) day at sea level for each engine is 4,119 pounds (1,868 kg).

Sixty percent of the thrust produced at sea level is from the bypass air and 40% is from the core airflow. Only 40% of the thrust produced at 45,000 feet is from bypass air, and then 60% is from the core airflow.

Overall dimensions of the PW545 are as follows:

- Diameter 32.0 in. (81.3 cm)
- Length 68.6 in. (174.2 cm)
- Inlet diameter 27.3 in. (69.3 cm)

NOTES




Figure 71-1. PW545 A/B Engine (Sheet 1 of 2)

NOTES




Figure 71-1. PW545 A/B Engine (Sheet 2 of 2)

NOTES




Figure 71-2. PW545C Engine (Sheet 1 of 2)

NOTES




Figure 71-2. PW545C Engine (Sheet 2 of 2)

NOTES




Figure 71-3. Bleed Valve Control Schematic

71-80

NOTES




Figure 71-4. Engine Fuel System (545A/B)



71-8

[illegible]

NOTES




Figure 71-6. Ignition (Sheet 1 of 4)

NOTES




Figure 71-6. Ignition (Sheet 2 of 4)

NOTES





Figure 71-6. Ignition (Sheet 3 of 4)

NOTES



NOTES




Figure 71-7. Rudder Bias and Thrust Reversers







Figure 71-8. Left Thrust Reversers—Normal Stow

LEGEND

-  LOW HYDRAULIC PRESSURE
-  HIGHT HYDRAULIC SUPPLY PRESSURE
-  RETURN PRESSURE

CONDITION:

THRUST REVERSER S STOWED

NOTES

[illegible]





Figure 71-9. Left Thrust Reverser—Armed and Unlocked



LH THRUST REVERSER ARMED & UNLOCKED
LH THRUST REVERSER DEPLOYED

[illegible]

71-80



71-18

CITATION 560XL/XLS/XLS+ SERIES MAINTENANCE SCHEMATIC MANUAL





Figure 71-12. L Start Procedures—5001-5268

NOTES




Figure 71-13. XL/XLS Start Procedures 5269 and Subsequent





Figure 71-14. XLS+ Start Procedure "A"



NOTES




Figure 71-15. XLS+ Start Procedure "B"